



INSTALLATION AND OPERATION MANUAL

CNGE2FE24MS

ENVIRONMENTALLY HARDENED MANAGED ETHERNET SWITCH WITH (24) 10/100TX + (2) 10/100/1000TX RJ45 OR 1000 FX SFP PORTS

V1.02 - October 2009

The ComNet[™] CNGE2FE24MS Managed Ethernet Switch provides transmission of (24) 10/100 BASE-TX and (2) 10/100/1000TX or 1000FX combo ports. Unlike most Ethernet switches, these environmentally hardened units are designed for deployment in difficult operating environments, and are available for use with either conventional CAT-5e copper or optical transmission media. The 24 electrical ports support the 10/100 Mbps Ethernet IEEE 802.3 protocol, and autonegotiating and auto-MDI/MDIX features are provided for simplicity and ease of installation. 2 ports are 10/100/1000 configurable for copper or fiber media for use with multimode or single mode optical fiber, selected by optional SFP modules. These network managed layer 2 switches are optically (1000 BASE-FX) and electrically compatible with any IEEE 802.3 compliant Ethernet devices. Plugand-play design ensures ease of installation, and no electrical or optical adjustments are ever required. The CNGE2FE24MS incorporates LED indicators for monitoring the operating status of the managed switch and network. These units are rack mountable.

FCC Warning

This Equipment has been tested and found to comply with the limits for a Class-A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. It may cause harmful interference to radio communications if this equipment is not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Mark Warning

This is a Class-A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Content

FCC Warning	i
CE Mark Warning	ii ii
Introduction	
Hardware Features	1
Software Feature	4
Package Contents	7
Hardware Description Physical Dimension	8 8
Front Panel	9
Rear Panel	9
LED Indicators	11
Cabling	12
Desktop Installation	16
Attaching Rubber Feet	16
Rack-mounted Installation	16
Network Application	18
X-Ring Application	19
Couple Ring Application	20
Dual Homing Application	21
Console Management Connecting to the Console Port	 22 22
Login in the Console Interface	22
CLI Management	23

Web-Based Management	26
About Web-based Management	26
Preparing for Web Management	26
System Login	27
System	28
System Information	28
IP Configuration	29
DHCP Server – System configuration	31
DHCP Server – Client Entries	32
DHCP Server - Port and IP Bindings	33
TFTP - Update Firmware	34
TFTP – Restore Configuration	34
TFTP - Backup Configuration	35
System Event Log – Syslog Configuration	35
System Event Log - SMTP Configuration	37
System Event Log - Event Configuration	39
Fault Relay Alarm	41
SNTP Configuration	42
IP Security	44
User Authentication	46
Advanced Configuration—Broadcast Storm Filter .	46
Advanced Configuration—Aging Time	47
Advanced Configuration—Jumbo Frame	48
1000TX Cable Length	49

Port	50
Port Statistics	50
Port Counters	51
Port Control	54
Port Trunk	56
Aggregator setting	56
Aggregator Information	58
State Activity	59
Port Mirroring	61
Rate Limiting	62
VLAN configuration	63
VLAN configuration - Port-based VLAN	63
802.1Q VLAN	67
Rapid Spanning Tree	72
RSTP - System Configuration	73
RSTP—Port Configuration	75
SNMP Configuration	77
System Configuration	77
Trap Configuration	79
SNMPV3 Configuration	80
QoS Configuration	
QoS Policy and Priority Type	83

IGMP Configuration	
LLDP Configuration	
X-Ring	
Security	
802.1X/Radius Configuration	89
MAC Address Table	92
Access Control List	
Factory Default	
Save Configuration	
System Reboot	
Troubleshooting Incorrect connections	
Diagnosing LED Indicators	100
Appendix A—RJ45 Pin Assignment 10 /100BASE-TX Pin outs	101 101
10/100Base-TX Cable Schematic	102
10/100/1000Base-TX Pin outs	103
10/100/1000Base-TX Cable Schematic	103
Appendix B—Command Sets Commands Set List	105 105
System Commands Set	105
Port Commands Set	109
Trunk Commands Set	111

VLAN Commands Set	113
Spanning Tree Commands Set	115
QOS Commands Set	118
IGMP Commands Set	118
Mac / Filter Table Commands Set	119
SNMP Commands Set	121
Port Mirroring Commands Set	124
802.1x Commands Set	124
TFTP Commands Set	127
SystemLog, SMTP and Event Commands Set	128
SNTP Commands Set	130
X-Ring Commands Set	132
LLDP Command Set	133
Access Control List Command Set	133

Introduction

The 24 10/100TX + 2 10/100/1000T/SFP Combo Managed Industrial Switch is a costeffective solution and meets the high reliability requirements demanded by industrial applications. Using fiber port can extend the connection distance that increases the network elasticity and performance.

Hardware Features

	IEEE 802.3 10Base-T Ethernet
IEEE Standard	IEEE 802.3u 100Base-TX / 100Base-FX
	IEEE802.3z Gigabit fiber
	IEEE802.3ab 1000Base-T
	IEEE802.3x Flow Control and Back Pressure
	IEEE802.3ad Port trunk with LACP
	IEEE802.1d Spanning Tree/ IEEE802.1w Rapid Spanning
	Tree
	IEEE802.1p Class of Service
	IEEE802.1Q VLAN Tag
	IEEE 802.1x User Authentication (Radius)
	IEEE802.1ab LLDP
	Back-plane (Switching Fabric): 8.8Gbps
Switch	Packet throughput ability (Full-Duplex):
Architecture	13.1Mpps@64bytes
	14,880 pps for 10Base-T Ethernet port
Transfer Rate	148,800 pps for 100Base-TX/FX Fast Ethernet port
	1,488,000 pps for Gigabit Fiber Ethernet port

Packet Buffer	4Mbits		
MAC address	8K MAC address table		
Flash ROM	4Mbytes		
DRAM	32Mbytes		
Jumbo Frame	9022bytes (for Gigabit Ports)		
	RS-232 console : Female DB-9		
Connector	10/100TX: 24 x RJ45		
	10/100/1000T/ Mini-GBIC Combo: 2 x RJ45 + 2 x SFP		
	sockets		
	DC-PWR1, DC-PWR2: Green, Fault: Red		
	Link/Activity (P1 ~ P26): Green		
	FDX (P1 ~ P24): Amber		
	FDX/COL (P25, P26): Amber		
	10Base-T: 2-pair UTP/STP Cat. 3, 4, 5, 5e cable		
	EIA/TIA-568 100-ohm (100m)		
Network Cable	100Base-TX: 2-pair UTP/STP Cat. 5/5e cable		
Network Cable	EIA/TIA-568 100-ohm (100m)		
	1000Base-TX: 2-pair UTP/STP Cat. 5e cable		
	EIA/TIA-568 100-ohm (100m)		
	DC 12V ~ 48V – A readily accessible disconnect device		
Power Supply	as part of the building installation shall be incorporated		
	into the fixed wiring. Moreover, The disconnect device		
	(appropriate circuit breaker) must be included in the		
	ungrounded supply conductor.		

Redundant Power Supply	DC 12V ~ 48V		
Power Consumption	16.2 Watts		
Operating Temp.	-40°C to 75°C		
Operation Humidity	5% to 95% (Non-condensing)		
Storage Temperature	-40°C to 85°C		
Case Dimension	440mm (W) x 280mm (D) x 44mm (H)		
Installation	19" Rack mount		
EMI	FCC Class A, CE EN61000-4-2 (ESD), CE EN61000-4-3 (RS), CE EN-61000-4-4 (EFT), CE EN61000-4-5 (Surge), CE EN61000-4-6 (CS), CE EN61000-4-8, CE EN61000-4-12, CE EN61000-6-2, CE EN61000-6-4, C-Tick		
Safety	UL, cUL, CE/EN60950-1		
Stability testing	IEC60068-2-32 (Free fall), IEC60068-2-27 (Shock), IEC60068-2-6 (Vibration)		

Software Feature

Management	SNMP v1 SNMP v2c SNMP v3 Web/Telnet/Console (CLI) RFC 2418 SNMP MIB, RFC 1213 MIBII, RFC 2011	
SNMP MIB	SNMP V2 MIB, RFC 1493 Bridge MIB, RFC 2674 VLAN MIB, RFC 1215 Trap MIB, RFC 1643 Ethernet Like, RFC 1757 RMON1, RSTP MIB, LLDP MIB, Private MIB	
VLAN	Port based VLAN, up to 24 groups IEEE802.1Q Tag VLAN Static VLAN groups up to 256, Dynamic VLAN group up to 2048, VLAN ID from 1 to 4096. GVRP up to 256 groups.	
Port Trunk with LACP	LACP Port Trunk: 13 Trunk groups/Maximum 4 trunk members	
LLDP	Supports LLDP to allow switch to advertise its identification and capability on the LAN	
Spanning Tree	Supports IEEE802.1d Spanning Tree and IEEE802.1w Rapid Spanning Tree	
X-Ring Supports X-Ring, Dual Homing, Couple Ring and Central Ring topology Provides redundant backup feature and the recover time below 20ms		

Quality of service	The quality of service determined by port, Tag and IPv4 Type of service, IPv4 Different Service	
Class of Service	Supports IEEE802.1p class of service, per port provides 4 priority queues	
Port Security	Supports 50 entries of MAC address for static MAC and another 50 for MAC filter	
Port Mirror	Supports 3 mirroring types: "RX, TX and Both packet"	
IGMP	Supports IGMP snooping v1, v2 256 multicast groups and IGMP query	
IP Security	Supports 10 IP addresses that have permission to access the switch management and to prevent unauthorized intruder	
Login Security	Supports IEEE802.1X Authentication/RADIUS	
Access Control List (ACL)	Supports up to 256 Policy	
Bandwidth Control	Support ingress packet filter and egress packet limit The egress rate control supports all of packet type and the limit rates are 0~100Mbps Ingress filter packet type combination rules are Broadcast/Multicast/Unknown Unicast packet, Broadcast/Multicast packet, Broadcast packet only and all of packet. The packet filter rate can be set from 0 to 100Mbps	

Flow Control	Supports Flow Control for Full-duplex and Back Pressure for Half-duplex		
System log	Supports System log record and remote system log server		
SMTP	Supports 1 SMTP Server and 6 e-mail accounts for receiving event alert		
Relay Alarm	Provides one relay output for port breakdown and power failure Alarm Relay current carry ability: 1A @ DC 24V		
SNMP Trap	 Device cold start, Authorization failure, X-Ring topology changed. Port link up/ link down. Trap station up to 3		
DHCP	Provides DHCP Client/DHCP Server/IP Relay functions		
DNS	Provides DNS client feature Supports Primary and Secondary DNS server		
SNTP	Supports SNTP to synchronize system clock in Internet		
Firmware Upgrade	Supports TFTP & Console firmware update		
Configuration Upload and Download	Supports binary format configuration file for system quick installation (TFTP backup and restore)		

Package Contents

Please refer to the package contents list below to verify them against the checklist.

- 24 10/100TX + 2 10/100/1000T/SFP Combo Managed Industrial Switch x 1
- User manual x 1
- Pluggable Terminal Block x 1
- Mounting plate x 2
- DB-9P/F TO DB-9P/M 150cm RoHS cable x 1
- Rubber feet

Compare the contents with the standard checklist above. If any item is damaged or missing, please contact the local dealer for service.

In this paragraph, the Industrial switch's hardware spec, port, cabling information, and wiring installation will be described.

Physical Dimension

24 10/100TX + 2 10/100/1000T/SFP Combo Managed Industrial Switch dimension (W x D x H) is **17.6" x 11.2" x 1.75" (440mm x 280mm x 44mm)**



Front Panel

The Front Panel of 24 10/100TX + 2 10/100/1000T/SFP Combo Managed Industrial Switch is shown as below:



Front Panel of the Managed Industrial Switch

Rear Panel

The rear panel of 24 10/100TX + 2 10/100/1000T/SFP Combo Managed Industrial Switch has one terminal block connector. The ten-pin screw clamp terminal strip is for power supply connections and connections to the fault relay. Redundant power sources may be used.

The fault relay can be configured to change from its normally open state in response to any or all of the following conditions using the GUI check boxes shown in the image below:

- failure of power supply 1
- failure of power supply 2
- failure or a port
- failure of a link to the port



Pin-outs follow:

PWR1

Pin 1 or Pin 2 = +12 to +48 VDC

Pin 3 or Pin 4 = -12 VDC to -48 VDC

PWR2

Pin 7 or Pin 8 = +12 to +48 VDC

Pin 9 or Pin 10 = -12 VDC to -48 VDC

Fault

Pin 5 and Pin 6 = normally open relay secondary, contacts rated at 24 VDC 1A max, resistive loads only



Rear Panel of the Managed Industrial Switch

LED Indicators

The diagnostic LEDs located on the front panel of the industrial switch provide real-time information of the system and optional status. The following table provides the description of the LED status and their meanings for the switch.

LED	Status	Description
	Green	DC power input 1 is active
	Off	DC power input 1 is inactive
DC-PWR2	Green	DC power input 2 is active
	Off	DC power input 2 is inactive
Fault	Red	DC power input 1 or 2 is inactive or port link down
	Off	DC power 1/DC Power 2/port linking are all active, or no power inputs
LNK/ACT (Port 1 ~ 26)	Green	The port is connecting with the device
	Blink	The port is receiving or transmitting data
	Off	No device attached
FDX	Amber	The port is operating in Full-duplex mode
(Port 1 ~ 24)	Off	In Half-duplex mode
FDX/COL (Port 25, 26)	Amber	The port is operating in Full-duplex mode
	Blink	Collision of Packets occurs in the port
	Off	In Half-duplex mode

Cabling

- Use four twisted-pair, Category 5e or above cabling for RJ45 port connection. The cable between the switch and the link partner (switch, hub, workstation, etc.) must be less than 100 meters (328 ft.) long.
- Fiber segment using a small form-factor pluggable, a single-mode connector can be applied to standard (such as 9/125 μm, 9.5/125 μm, or 10/125 μm) single-mode fiber cable. Fiber spans are dependent on SFP used.
- Fiber segment using a small form-factor pluggable, a multi-mode connector can be applied to standard (such as 50 or 62.5/125 µm) multi-mode fiber cable. User can connect two devices up to 2km distances.

To connect the transceiver and LC cable, please follow the steps shown below:

First, insert the transceiver into the SFP module. Notice that the triangle mark is the bottom of the module.



Transceiver to the SFP module



Transceiver Inserted

Second, insert the fiber cable of LC connector into the transceiver.



LC connector to the transceiver

To remove the LC connector from the transceiver, please follow the steps shown below:



First, press the upper side of the LC connector to release from the transceiver and pull it out.

Remove LC connector

Second, push down the metal loop and pull the transceiver out by the plastic handle.



Pull out from the transceiver

Desktop Installation

Set the Switch on a sufficiently large flat space with a power outlet nearby. The surface where you put your switch should be clean, smooth, level and sturdy.

Make sure there is enough clearance around the Switch to allow attachment of cables, power cord and allow air circulation.

Attaching Rubber Feet

- A. Make sure mounting surface on the bottom of the Switch is grease and dust free.
- B. Remove adhesive backing from your Rubber Feet.
- C. Apply the Rubber Feet to each corner on the bottom of the Switch. These footpads can prevent the Switch from shock/vibration.



Attaching Rubber Feet to each corner on the bottom of the Switch

Rack-mounted Installation

The Switch comes with a rack-mounted kit and can be mounted in an EIA standard size, 19-inch Rack. It can be placed in a wiring closet with other equipment.

Perform the following steps to rack-mount the switch:

A. Position one plate to align with the holes on one side of the Switch and secure it with the smaller plate screws. Then, attach the remaining plate to the other side of the Switch.



Attach mounting plates with screws

B. After attaching both mounting plates, position the Switch in the rack by lining up the holes in the plates with the appropriate holes on the rack. Secure the Switch to the rack with a screwdriver and the rack-mounting screws.



Mount the Switch in an EIA standard 19-inch Rack

Note: For proper ventilation, allows about at least 4 inches (10 cm) of clearance on the front and 3.4 inches (8 cm) on the back of the Switch. This is especially important for enclosed rack installation.

Network Application

This segment provides the samples to help user have more actual idea of industrial switch application. For the sample applications of the industrial switch, see the figures below.



X-Ring Application

The industrial switch supports the X-Ring protocol that can help the network system to recover from network connection failure within 20ms or less, and make the network system more reliable. The X-Ring algorithm is similar to Spanning Tree Protocol (STP) and Rapid STP (RSTP) algorithm but its recovery time is less than STP/RSTP. The figure below is a sample of X-Ring application.



Couple Ring Application

In the network, it may have more than one X-Ring group. Using the coupling ring function can connect each X-Ring for the redundant backup. It can ensure the transmissions between two ring groups not to fail. The following figure is a sample of coupling ring application.



Dual Homing Application

Dual Homing function is to prevent the connection loss from between X-Ring group and upper level/core switch. Assign two ports to be the Dual Homing port that is backup port in the X-Ring group. The Dual Homing function only works when the X-Ring function is active. Each X-Ring group only has one Dual Homing port.

[NOTE] In Dual Homing application architecture, the upper level switches need to enable the Rapid Spanning Tree protocol.



Connecting to the Console Port

Use the supplied RS-232 cable to connect between a terminal/PC and the console port. The terminal or PC to being connected must support the terminal emulation program.



PC or Workstation Connecting the switch to a terminal via RS-232 cable

Login in the Console Interface

When the connection between Switch and PC is ready, turn on the PC and run a terminal emulation program or **Hyper Terminal** and configure its **communication parameters** to match the following default characteristics of the console port:

Baud Rate: 9600 bps Data Bits: 8 Parity: none Stop Bit: 1

Flow control: None

2 Properties	-	1
int Settings		
Bits per second:	9600	
<u>D</u> ata bits:	8	<u> </u>
<u>P</u> arity:	None	<u>•</u>
<u>S</u> top bits:	1	
Elow control:	None	
<u>A</u> dvanced		Bestore Defaults
	ĸ 1	Cancel Anolu

The settings of communication parameters

After finishing the parameter settings, click '**OK**'. When the blank screen shows up, press **Enter** key to bring out the login prompt. Key in '**admin**' (default value) for both User name and Password (use **Enter** key to switch), then press **Enter** key and the Main Menu of console management appears.



Console login interface

CLI Management

The system supports the console management—CLI command. After you log in on the system, you will see a command prompt. To enter CLI management interface, type in "enable" command.



CLI command interface

The following table lists the CLI commands and description.

Modes	Access	Brompt	Exit	About This Mode
woues	Method	Prompt	Method	About This Mode
				The user commands
				available at the user
				level are a subset of
	Begin a		Enter	those available at the
User EXEC	session with	switch>	logout or	privileged level.
	your switch.		quit.	Use this mode to
				 Perform basic tests.
				 Display system
				information.
				The privileged
	Enter the			command is the
Drivilogod	enable		Enter	advanced mode.
Fivileged	command	switch#	disable to	Use this mode to
EXEC	while in User		exit.	 Display advanced
	EXEC mode.			function status
				 Save configuration

Global Configuration	Enter the configure command while in privileged EXEC mode.	switch (config)#	To exit to privileged EXEC mode, enter exit or end	Use this mode to configure those parameters that are going to be applied to your switch.
VLAN database	Enter the vlan database command while in privileged EXEC mode.	switch (vlan)#	To exit to user EXEC mode, enter exit .	Use this mode to configure VLAN- specific parameters.
Interface configuration	Enter the interface of fast Ethernet command (with a specific interface) while in global configuration mode	switch (config-if)#	To exit to global configuratio n mode, enter exit . To exit to privileged EXEC mode, enter exit or end .	Use this mode to configure parameters for the switch and Ethernet ports.

This section introduces the configuration and functions of the Web-Based management.

About Web-based Management

There is an embedded HTML web site residing in flash memory on CPU board of the switch, which offers advanced management features and allows users to manage the switch from anywhere on the network through a standard browser such as Microsoft Internet Explorer.

The Web-Based Management supports Internet Explorer 6.0 or later version. And, it is applied for Java Applets for reducing network bandwidth consumption, enhance access speed and present an easy viewing screen.

Preparing for Web Management

Before using the web management, install the industrial switch on the network and make sure that any one of the PCs on the network can connect with the industrial switch through the web browser. The industrial switch default value of IP, subnet mask, username and password are listed as below:

- IP Address: **192.168.10.1**
- Subnet Mask: 255.255.255.0
- Default Gateway: 192.168.10.254
- User Name: admin
- Password: admin

System Login

- 1. Launch the Internet Explorer on the PC
- 2. Key in "http:// "+" the IP address of the switch", and then Press "Enter".



- 3. The login screen will appear right after.
- 4. Key in the user name and password. The default user name and password are the same as '**admin'**
- 5. Press **Enter** or click **OK**, and then the home screen of the Web-based management shows up.



System

System Information

Assign the system name and location and view the system information.

- System Name: Assign the system name of the switch (The maximum length is 64 bytes)
- **System Description:** Describes the switch.
- System Location: Assign the switch physical location (The maximum length is 64 bytes).
- **System Contact:** Enter the name of contact person or organization.
- **Firmware Version:** Displays the switch's firmware version.
- **Kernel Version:** Displays the kernel software version.
- MAC Address: Displays the unique hardware address assigned by manufacturer (default).
- And than, click (Apply

ystem Name	CNGE2FE24MS		
System Description	2 GE 24 FE Managed Switch		
System Location			
System Contact			
Please use	Apply Help Save Configuration to permanently save the updates.		
	Firmware Version v2.10		
	Firmware Version v2.10 Kernel Version v5.57		
	Firmware Version v2.10 Kernel Version v5.57 MAC Address 002238030034		

System information interface

IP Configuration

User can configure the IP Settings and DHCP client function in here.

- DHCP Client: Enable or disable the DHCP client function. When DHCP client function is enabled, the industrial switch will be assigned an IP address from the network DHCP server. The default IP address will be replaced by the assigned IP address on DHCP server. After user click Apply, a popup dialog shows up. It is to inform the user that when the DHCP client is enabled, the current IP will lose and user should find the new IP on the DHCP server.
- IP Address: Assign the IP address that the network is using. If DHCP client function is enabled, and then the user doesn't need to assign the IP address. And, the network DHCP server will assign the IP address displaying in this column for the industrial switch. The default IP is 192.168.10.1.
- Subnet Mask: Assign the subnet mask to the IP address. If DHCP client function is enabled, and then the user does not need to assign the subnet mask.
- Gateway: Assign the network gateway for the industrial switch. The default gateway is 192.168.10.254.
- **DNS1:** Assign the primary DNS IP address.
- **DNS2:** Assign the secondary DNS IP address.
- And then, click Apply
| IP Conf | iguration |
|--|--|
| DHCP Clier | nt : Disable 💌 |
| IP Address | 192.168.10.1 |
| Subnet Mask | 255.255.255.0 |
| Gateway | 192.168.10.254 |
| DNS1 | 0.0.0.0 |
| DNS2 | 0.0.0.0 |
| Apply
Please use Save Configuration | Help
n to permanently save the updates. |

IP configuration interface

DHCP Server – System configuration

DHCP is the abbreviation of Dynamic Host Configuration Protocol that is a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, the device's IP address can even change while it is still connected. DHCP also supports a mix of static and dynamic IP addresses. Dynamic addressing simplifies network administration because the software keeps track of IP addresses rather than requiring an administrator to manage the task. This means that a new computer can be added to a network without the hassle of manually assigning it a unique IP address. The system provides the DHCP server function. Enable the DHCP server function, the switch system will be a DHCP server.

- DHCP Server: Enable or Disable the DHCP Server function. Enable—the switch will be the DHCP server on your local network.
- Low IP Address: Type in an IP address. Low IP address is the beginning of the dynamic IP range. For example, dynamic IP is in the range between 192.168.10.100
 ~ 192.168.10.200. In contrast, 192.168.10.100 is the Low IP address.
- High IP Address: Type in an IP address. High IP address is the end of the dynamic IP range. For example, dynamic IP is in the range between 192.168.10.100 ~ 192.168.10.200. In contrast, 192.168.10.200 is the High IP address.
- **Subnet Mask:** Type in the subnet mask of the IP configuration.
- **Gateway:** Type in the IP address of the gateway in your network.
- **DNS:** Type in the Domain Name Server IP Address in your network.
- Lease Time (sec): It is the time period that system will reset the dynamic IP assignment to ensure the dynamic IP will not been occupied for a long time or the server doesn't know that the dynamic IP is idle.
- And then, click (Apply



System Configuration	Client E	ntries	Port and IP Binding
	DHCP Server	Disable 💌	
	Low IP Address	192.168.10.100	
	High IP Address	192.168.10.200	
	Subnet Mask	255.255.255.0	
	Gateway	192.168.10.254	
	DNS	0.0.0.0	
	Lease Time (sec)	86400	
	Lease Time (sec)	00400	

DHCP Server Configuration interface

DHCP Server – Client Entries

When the DHCP server function is active, the system will collect the DHCP client information and displays it at this tab.



DHCP Server - Port and IP Bindings

Assign the dynamic IP address to the port. When the device is connecting to the port and asks for IP assigning, the system will assign the IP address that has been assigned before to the connected device.

stem Configuration	Client Entries	Port and IP Binding
	Port IP	
	Port.01 0.0.0.0	
	Port.02 0.0.0.0	
	Port.03 0.0.0.0	
	Port.04 0.0.0.0	
	Port.05 0.0.0.0	
	Port.06 0.0.0.0	
	Port.07 0.0.0.0	
	Port.08 0.0.0.0	
	Port.09 0.0.0.0	
	Port.10 0.0.0.0	
	Port.11 0.0.0.0	
	Port.12 0.0.0.0	
	Port.13 0.0.0.0	
	Port.14 0.0.0.0	
	Port.15 0.0.0.0	
	Port.16 0.0.0.0	
	Port.17 0.0.0.0	
	Port.18 0.0.0.0	
	Port.19 0.0.0.0	
	Port.20 0.0.0.0	
	Port.21 0.0.0.0	
	Port.22 0.0.0.0	
	Port.23 0.0.0.0	
	Port.24 0.0.0.0	
	Port.25 0.0.0.0	
	Port.26 0.0.0.0	
	Apply Help	

TFTP - Update Firmware

It provides the functions that allow user to update the switch firmware. Before updating, make sure the TFTP server is ready and the firmware image is located on the TFTP server.

- 1. TFTP Server IP Address: Type in your TFTP server IP.
- 2. Firmware File Name: Type in the name of firmware image.
- 3. Click Apply



Update Firmware interface

TFTP – Restore Configuration

You can restore the configuration from TFTP server. Before doing that, you must put the image file on TFTP server first and the switch will download back the flash image.

- 1. **TFTP Server IP Address:** Type in the TFTP server IP.
- 2. Restore File Name: Type in the correct file name for restoring.
- 3. Click Apply.



Restore Configuration interface

TFTP - Backup Configuration

You can save the current configuration from flash ROM to TFTP server for restoring later.

- 1. TFTP Server IP Address: Type in the TFTP server IP.
- 2. Backup File Name: Type in the file name.
- 3. Click Apply.

date Firmware	Res	tore Configuration	Backup Configuration
	3/65		
TFTP Server	IP Address	192.168.10.2	
Backup Fil	le Name	data.bin	

Backup Configuration interface

System Event Log – Syslog Configuration

Configure the system event mode to collect system log.

 Syslog Client Mode: Select the system log mode—Client Only, Server Only, or Both.

- 2. System Log Server IP Address: Assign the system log server IP.
- 3. When Syslog Client Mode is set as Client Only, the system event log will only be reserved in the switch's RAM until next reboot. When Syslog Client Mode is set as Server Only, the system log will only be sent to the syslog server and you have to type the IP address of the Syslog Server in the "Syslog Server IP Address" column. If the Syslog Client Mode is set as Both, the system log will be reserved in the switch's RAM and sent to server.
- 4. Click Reload to refresh the events log.
- 5. Click (clear) to clear all current events log.
- 5. After configuring, Click (Apply



Syslog Configuration interface

System Event Log - SMTP Configuration

You can set up the mail server IP, mail account, password, and forwarded email account for receiving the event alert.

- 1. **Email Alert:** Enable or disable the email alert function.
- 2. **SMTP Server IP:** Set up the mail server IP address (when **Email Alert** enabled, this function will then be available).
- Sender: Type in an alias of the switch in complete email address format, e.g. switch101@123.com, to identify where the event log comes from.

- 4. **Authentication:** Tick the checkbox to enable this function, configuring the email account and password for authentication (when **Email Alert** enabled, this function will then be available).
- Mail Account: Set up the email account, e.g. johnadmin, to receive the alert. It must be an existing email account on the mail server, which you had set up in SMTP Server IP Address column.
- 6. **Password:** Type in the password to the email account.
- 7. Confirm Password: Reconfirm the password.
- Rcpt e-mail Address 1 ~ 6: You can also assign up to 6 e-mail accounts to receive the alert.

9. Click Apply.



SMTP Configuration interface

System Event Log - Event Configuration

The user must enable the Syslog or SMTP first to configure the condition setting in this page. When the **Syslog/SMTP** checkbox is marked, the event log will be sent to system log server/SMTP server. Also, per port log (link up, link down, and both) events can be sent to the system log server/SMTP server with the respective checkbox ticked. After

configuring, click (Apply) to have the setting taken effect.

- System event selection: There are 4 event types—Device cold start, Device warm start, Authentication Failure, and X-ring topology change. Before you can tick the checkbox of each event type, the Syslog Client Mode column on the Syslog Configuration tab/E-mail Alert column on the SMTP Configuration tab must be enabled first.
 - Device cold start: When the device disconnects the power supply and reconnect to it, the system will issue a log event.
 - > **Device warm start:** When the device reboots, the system will issue a log event.
 - Authentication Failure: When the authentication fails, the system will issue a log event.
 - X-ring topology change: When the X-ring topology has changed, the system will issue a log event.
- Port event selection: Also, before the drop-down menu items are available, the Syslog Client Mode column on the Syslog Configuration tab and the E-mail Alert column on the SMTP Configuration tab must be enabled first. Those drop-down menu items have 3 selections—Link UP, Link Down, and Link UP & Link Down. Disable means no event will be sent to the system log server/SMTP server.
 - Link UP: The system will issue a log message when port connection is up only.
 - Link Down: The system will issue a log message when port connection is down only.
 - Link UP & Link Down: The system will issue a log message when port connection is up and down.

g Configura	ation S	MTP Configurat	tion Ever	nt Configur
	Sv	stem Event Se	lection	
	Event Typ	e	Syslog	SMTP
	Device cold s	start		
	Device warm	start		2
	Authentication	failure		
	X-Ring topology	change		V
	P	ort Event Sele	ection	
Port	Syslo	g	SMTP	
Port.01	Disable	*	Disable	*
Port.02	Link Up		Disable	*
Port.03	Link Down	Down	Disable	~
Port.04		DOWN	Disable	*
Port.05	Disable	~	Disable	*
Port.06	Disable	*	Disable	*
Port.07	Disable	~	Disable	*
Port.08	Disable	*	Disable	*
Port.09	Disable	Y	Disable	*
Port.10	Disable	*	Disable	*
Port.11	Disable	1	Disable	1
Port.12	Disable	1	Disable	*
Port.13	Disable	*	Disable	*
Port.14	Disable	×	Disable	~
Port.15	Disable	*	Disable	*
Port.16	Disable	*	Disable	×
Port.17	Disable	*	Disable	*
Port.18	Disable	*	Disable	*
Port.19	Disable	N.	Disable	*
Port.20	Disable	1	Disable	~
Port.21	Disable	~	Disable	*
Port.22	Disable	*	Disable	*
Port.23	Disable	×	Disable	*
Port.24	Disable	×	Disable	~
Port.25	Disable	*	Disable	*
Port.26	Disable	v	Disable	*
			and the second second	100

Event Configuration interface

Fault Relay Alarm

- Power Failure: Tick the checkbox to enable the function of lighting up the FAULT LED on the panel when power fails.
- Port Link Down/Broken: Tick the checkbox to enable the function of lighting up FAULT LED on the panel when Ports' states are link down or broken.

Fault Relay Alarm
Power Failure
Power 1 Power 2
Port Link Down/Broken
Port 1 Port 2
Port 3 Port 4
Port 5 Port 6
Port 7 Port 8
Port 9 Port 10
Port 11 Port 12
Port 13 Port 14
Port 15 Port 16
Port 17 Port 18
Port 19 Port 20
Port 21 Port 22
Port 23 Port 24
Port 25 Port 26
Apply Please use Save Configuration to permanently save the updates.

Fault Relay Alarm interface

SNTP Configuration

You can configure the SNTP (Simple Network Time Protocol) settings. The SNTP allows you to synchronize switch clocks in the Internet.

- 1. **SNTP Client:** Enable/disable SNTP function to get the time from the SNTP server.
- 2. **Daylight Saving Time:** Enable/disable daylight saving time function. When daylight saving time is enabled, you need to configure the daylight saving time period.
- 3. **UTC Timezone:** Set the switch location time zone. The following table lists the different location time zone for your reference.

Local Time Zone	Conversion from UTC	Time at 12:00 UTC
November Time Zone	- 1 hour	11am
Oscar Time Zone	-2 hours	10 am
ADT - Atlantic Daylight	-3 hours	9 am
AST - Atlantic Standard EDT - Eastern Daylight	-4 hours	8 am
EST - Eastern Standard CDT - Central Daylight	-5 hours	7 am
CST - Central Standard MDT - Mountain Daylight	-6 hours	6 am
MST - Mountain Standard PDT - Pacific Daylight	-7 hours	5 am
PST - Pacific Standard ADT - Alaskan Daylight	-8 hours	4 am
ALA - Alaskan Standard	-9 hours	3 am
HAW - Hawaiian Standard	-10 hours	2 am
Nome, Alaska	-11 hours	1 am

CET - Central European		
FWT - French Winter		
MET - Middle European	+1 hour	1 pm
MEWT - Middle European Winter		
SWT - Swedish Winter		
EET - Eastern European, USSR	±2 bours	2 nm
Zone 1	+2 Hours	2 pm
BT - Baghdad, USSR Zone 2	+3 hours	3 pm
ZP4 - USSR Zone 3	+4 hours	4 pm
ZP5 - USSR Zone 4	+5 hours	5 pm
ZP6 - USSR Zone 5	+6 hours	6 pm
WAST - West Australian Standard	+7 hours	7 pm
CCT - China Coast, USSR Zone 7	+8 hours	8 pm
JST - Japan Standard, USSR Zone 8	+9 hours	9 pm
EAST - East Australian Standard		
GST	+10 hours	10 pm
Guam Standard, USSR Zone 9		
IDLE - International Date Line		
NZST - New Zealand Standard	+12 hours	Midnight
NZT - New Zealand		

- 4. **SNTP Sever URL:** Set the SNTP server IP address.
- 5. **Switch Timer:** Displays the current time of the switch.
- 6. **Daylight Saving Period:** Set up the Daylight Saving beginning time and Daylight Saving ending time. Both will be different in every year.
- 7. **Daylight Saving Offset (mins):** For non-US and European countries, specify the amount of time for day light savings.
- 8. Click Apply.

SN	ITP Configuration SNTP Client : Enable 💌
UTC Timezone	(GMT-05:00)Eastern Time (US & Canada)
SNTP Server URL	76.168.30.201
Switch Timer	
Daylight Saving Period	20040101 00:0 20040101 00:0
Daylight Saving Offset(mins)	0
Please use Sa	Apply Help we Configuration to permanently save the updates.

SNTP Configuration interface

IP Security

IP security function allows the user to assign 10 specific IP addresses that have permission to access the switch through the web browser for the securing switch management.

- IP Security Mode: When this option is in Enable mode, the Enable HTTP Server and Enable Telnet Server checkboxes will then be available.
- Enable HTTP Server: When this checkbox is ticked, the IP addresses among Security IP1 ~ IP10 will be allowed to access this switch via HTTP service. When IP Security is Enable and this checkbox is not ticked, no user is allowed to login via HTTP.
- Enable Telnet Server: When this checkbox is ticked, the IP addresses among Security IP1 ~ IP10 will be allowed to access this switch via telnet service. When IP Security is Enable and this checkbox is not ticked, no user is allowed to login via Telnet.
- Security IP 1 ~ 10: The system allows the user to assign up to 10 specific IP

addresses for access security. Only these 10 IP addresses can access and manage the switch through the HTTP/Telnet service.

And then, click (Apply) to have the configuration taken effect.

[NOTE] Remember to execute the "Save Configuration" action, otherwise the new configuration will lose when the switch powers off.

IP Security M ♥ Enable HTTP ♥ Enable Telne	lode: Enable 💙 Server et Server
Security IP1	192.168.16.77
Security IP2	192.168.16.89
Security IP3	192.168.16.120
Security IP4	0.0.0.0
Security IP5	0.0.0.0
Security IP6	0.0.0.0
Security IP7	0.0.0.0
Security IP8	0.0.0.0
Security IP9	0.0.0.0
Security IP10	0.0.0.0
Apply Please use Save Configuration	Help to permanently save the updates

IP Security interface

User Authentication

Change web management login user name and password for the management security issue.

- **User name:** Type in the new user name (The default is 'root')
- **Password:** Type in the new password (The default is 'root')
- **Confirm password:** Re-type the new password
- And then, click (Apply



User Authentication interface

Advanced Configuration—Broadcast Storm Filter

This page enables user to select the filter packet type. All the packet types filtering conditions could be selected at the same time.

- Flooded Unicast/Multicast Packets: When this check box is ticked, the switch will filter the packet type of Flooded Unicast/Multicast.
- Control Packets: Tick this check box to enable the switch to filter the packet type of control.

- IP Multicast Packets: Tick this check box to enable the switch to filter the packet type of IP Multicast.
- Broadcast Packets: Tick this check box to enable the switch to filter the packet type of broadcast.
- Broadcast Storm Rate: User can set the filtering rate range from 1/2 of ingress to 1/16 of ingress.
- And then, click (Apply) to have the configuration taken effect.



Broadcast Storm Filter interface

Advanced Configuration—Aging Time

This tab is used to assign the aging time of MAC table.

- Aging Time of MAC Table: Select the aging time as OFF, 150 sec, 300 sec, or 600 sec. When MAC table is not used within the aging time, the MAC address table will then be cleared.
- Auto Flush MAC Table When Link Down: When this item is enabled, the switch will flush its MAC address table when link down.

And then, click (Apply) to have the configuration taken effect.



Aging Time interface

Advanced Configuration—Jumbo Frame

This tab is used to enable the jumbo frame function.

- Enable Jumbo Frame: When this check box is ticked, the Gigabit port of the switch extends the frame to 9022bytes.
- And then, click (Apply) to have the configuration taken effect.

Advanced Cor	nfiguration -	Jumbo Frame
Broadcast Storm Filter	Aging Time	Jumbo Frame
	Enable Jumbo Frame	
Please use Save C	Apply Help Configuration to permanently	save the updates.

Jumbo Frame interface

1000TX Cable Length

This tab is used to allow port 25 and port 26 to support Cat5e or Cat6 cable length longer than 10 meters.

- To support long cable: Uncheck the check box for the port(s) you would like to effect.
- And then, click Apply to have the configuration taken effect.

TOUDIA Cable Lengt	h
Enable Port.25 Cable < 10 Meters	
Enable Port.26 Cable < 10 Meters	

Jumbo Frame interface

Port

Port Statistics

The following information provides the current port statistic information.

- **Port:** Displays the port number.
- **Type:** Displays the media type of the port.
- Link: The status of linking—'Up' or 'Down'.
- State: The user can set the state of the port as 'Enable' or 'Disable' via Port Control. When the state is disabled, the port will not transmit or receive any packet.
- **Tx Good Packet:** The counts of transmitting good packets via this port.
- Tx Bad Packet: The counts of transmitting bad packets (including undersize [less than 64 bytes], oversize, CRC Align errors, fragments and jabbers packets) via this port.
- **Rx Good Packet:** The counts of receiving good packets via this port.
- Rx Bad Packet: The counts of receiving bad packets (including undersize [less than 64 bytes], oversize, CRC error, fragments and jabbers) via this port.
- **Tx Abort Packet:** The aborted packet while transmitting.
- Packet Collision: The counts of collision packet.
- Packet Dropped: The counts of dropped packet.
- **Rx Bcast Packet:** The counts of broadcast packet.
- Rx Mcast Packet: The counts of multicast packet.
- Click Clear to clean all counts.

Port	Туре	Link	State	Tx Good Packet	Tx Bad Packet	Rx Good Packet	Rx Bad Packet	Tx Abort Packet	Packet Collision	Packet Dropped	RX Bcast Packet	RX Mcast Packet
Port.01	100TX	Down	Enable	O	0	0	0	0	0	0	0	0
Port.02	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.03	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.04	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.05	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.06	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.07	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.08	100TX	Down	Enable	0	0	0	0	0	0	0	Q	0
Port.09	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.10	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.11	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.12	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.13	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.14	100TX	Down	Enable	0	0	0	0	0	O	0	0	0
Port.15	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.16	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.17	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.18	100TX	Up	Enable	83	0	151	0	0	0	40	44	6
Port.19	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.20	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.21	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.22	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.23	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.24	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
Port.25	1GTX/mGBIC	Down	Enable	0	0	0	0	D	0	0	0	0
Port.26	1GTX/mGBIC	Down	Enable	8	0	0	0	0	D	0	a	0
						lear	Help	<u>k</u>			-	

Port Statistics interface

Port Counters

This chart displays the transmitted and received traffic of single port.

- Select Port: Pull down the menu bar to select a particular port, and then the counters for the port will be displayed.
- **RxBcastPkt:** The number of good broadcast packets received.
- RxOctel: The number of octels of data received (including those in bad packet, excluding framing bits but including FCS octels, excluding RxPausePkt).

- RxMcastPkt: The number of good multicast packets received except broadcast packets).
- RxFCSErr: The number of packets received that had a bad FCS or RX ER asserted with the proper and integral octels.
- RxOverSizePkt: The number of packets received that were longer than Max_Pkt_Len (=1522 bytes) and were otherwise well formed.
- RxAlignErr: The number of packets received that had a bad FCS or RX_ER asserted with the proper and non-integral octels.
- RxJabber: The number of packets received that were longer than Max_Pkt_Len (=1522 bytes) and had a bad FCS or RX_ER asserted.
- RxFragment: The number of packets received that were less than 64 octels long and had a bad FCS or RX ER asserted.
- RxUndersizePkt: The number of packets received that were less than 64 octels long and were otherwise well formed.
- RxPkt64: The number of packets received that were 64 octels in length including bad packets but excluding RxPausePkt.
- RxPkt65to127: The number of packets received that were between 65 and 127 octels in length (including error packets).
- RxPkt128to255: The number of packets received that were between 128 and 255 octels in length (including error packets).
- RxPkt256to511: The number of packets received that were between 256 and 511 octels in length (including error packets).
- RxPkt512to1023: The number of packets received that were between 511 and 1023 octels in length (including error packets).
- RxPkt1024to1522: The number of packets received that were between 1024 and the Max Pkt Len (=1522 bytes) octels in length (including error packets).
- **TxUcastPkt:** The number of unicast packet transmitted.
- **TxBcastPkt:** The number of broadcast packet transmitted.
- TxOctel: The number of octels transmitted (only for good packets excluding TxPausePkt).

- **TxSingleCollisn:** The number of successfully transmitted packets which transmission is inhibited by exactly one collision.
- TxMultiCollisn: The number of successfully transmitted packets which transmission is inhibited by more than one collision.
- **TxCollisn:** The number of collisions on this Ethernet segment.
- TxDefferTrans: The number of packets for which the first transmission attempt is delayed because medium is busy.
- DropFwdLkup: The number of unicast packets dropped after forwarding table lookup.
- DropIn: The number of packets dropped because the input FIFO overrun and the FC violation.
- **TxMcst:** The number of multicast packet transmitted.
- **TxPause:** The number of Pause Packet transmitted.
- **RxPause:** The number of Pause Packet received.
- **TxUnderrun:** The number of packets dropped because the output FIFO underrun.
- Click Clear to reset the figures.

Port Counters								
Select Port: Por	rt.18 💙							
RxBcastPkt	RxOctet	RxMcastPkt	RxFCSErr					
44	31540	6	0					
RxOverSizePkt	RxAlignErr	RxJabber	RxFragment					
0	0	0	0					
RxUnderSizePkt	RxPkt64	RxPkt65to127	RxPkt128to255					
0	132	60	20					
RxPkt256to511	RxPkt512to1023	RxPkt1024to1522	TxUcastPkt					
33	2	0	184					
TxBcastPkt	TxOctet	TxSingleCollisn	TxMultiCollisn					
0	100843	0	0					
TxCollisn	TxDefferTrans	DropFwdLkup	DropIn					
0	0	40	0					
TxMcst	TxPause	RxPause	TxUnderrun					
0	0	0	0					
	Clear	Help						

Port Control

In Port control, you can view and set the operation mode of each port.

- 1. **Port:** Select the port that you want to configure.
- 2. **State:** Current port status. The port can be set to disable or enable mode. *If the port state is set as 'Disable', it will not receive or transmit any packet.*
- 3. **Negotiation:** Auto and Force. Being set as Auto, the speed and duplex mode are negotiated automatically. When you set it as Force, you have to assign the speed and duplex mode manually.
- 4. **Speed:** It is available for selecting when the Negotiation column is set as Force. When the Negotiation column is set as Auto, this column is read only.
- Duplex: It is available for selecting when the Negotiation column is set as Force.
 When the Negotiation column is set as Auto, this column is read only.
- 6. Flow Control: Set flow control function as Enable or Disable. When enabled, once the device exceed the input data rate of another device as a result the receiving device will send a PAUSE frame which halts the transmission of the sender for a specified period of time. When disabled, the receiving device will drop the packet if too much to process.
- Security: Once the Security selection is set as 'On', any access from the device that connects to this port will be blocked unless the MAC address of the device is included in the static MAC address table. See the segment of MAC Address Table -Static MAC Addresses.
- 8. Click (Apply) to make the configuration taken effect.

Port	State	Negotiation	Speed	Duplex	Flow Control	Security
Port.01 Port.02 Port.03 Port.04	Enable 👻	Auto 👻	144	Full	Enable 😽	Off 👻

Please use Save Configuration to permanently save the updates.

Port	Group ID	Type	Link	State	Negotiation	Speed Duplex	Flow Control	Security
and the		2462			and Barnanon	Config Actual	Config Actual	
Port.01	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.02	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.03	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.04	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.05	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.06	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.07	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.08	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.09	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.10	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.11	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.12	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.13	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.14	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.15	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.16	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.17	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.18	N/A	100TX	Up	Enable	Auto	100 Full 100 Full	Enable ON	OFF
Port.19	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.20	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.21	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.22	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.23	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.24	N/A	100TX	Down	Enable	Auto	100 Full N/A	Enable N/A	OFF
Port.25	N/A	1GTX/mGBIC	Down	Enable	Auto	1G Full N/A	Enable N/A	OFF
Port.26	N/A	1GTX/mGBIC	Down	Enable	Auto	1G Full N/A	Enable N/A	OFF

Port Control interface

Port Trunk

Port trunking is the combination of several ports or network cables to expand the connection speed beyond the limits of any one single port or network cable. Link Aggregation Control Protocol (LACP), which is a protocol running on layer 2, provides a standardized means in accordance with IEEE 802.3ad to bundle several physical ports together to form a single logical channel. All the ports within the logical channel or so-called logical aggregator work at the same connection speed and LACP operation requires full-duplex mode.

Aggregator setting

- System Priority: A value that is used to identify the active LACP. The switch with the lowest value has the highest priority and is selected as the active LACP peer of the trunk group.
- Group ID: There are 13 trunk groups to be selected. Assign the "Group ID" to the trunk group.
- LACP: When enabled, the trunk group is using LACP. A port that joins an LACP trunk group has to make an agreement with its member ports first. Please notice that a trunk group, including member ports split between two switches, has to enable the LACP function of the two switches. When disabled, the trunk group is a static trunk group. The advantage of having the LACP disabled is that a port joins the trunk group without any handshaking with its member ports; but member ports won't know that they should be aggregated together to form a logic trunk group.
- Work ports: This column field allows the user to type in the total number of active port up to four. With LACP static trunk group, e.g. you assign four ports to be the members of a trunk group whose work ports column field is set as two; the exceed ports are standby/redundant ports and can be aggregated if working ports fail. If it is a static trunk group (non-LACP), the number of work ports must equal the total number of group member ports.

- Select the ports to join the trunk group. The system allows a maximum of four ports to be aggregated in a trunk group. Click and the ports focused in the right side will be shifted to the left side. To remove unwanted ports, select the ports and click Remove>>>
- When LACP enabled, you can configure LACP Active/Passive status for each port on the State Activity tab.
- Apply Click
 - Delete to delete Trunk Group. Select the Group ID and click Delete Use



2		System Priority		
		1		
	Group ID	Trunk.1 👻		
	LACP	Enable 💌		
	Vork Ports	4		
	Port.01 Port.02	\frown	Port.05 A Port.06	
	Port.03 Port.04	< <add< td=""><td>Port.07</td><td>0</td></add<>	Port.07	0
		\frown	Port.10	
4		Remove>>	Port.12	

Port Trunk—Aggregator Setting interface (four ports are added to the left field with LACP enabled)

Aggregator Information

When you have setup the aggregator setting with LACP disabled, you will see the local static trunk group information in here.

- 1. Group Key: Displays the trunk group ID.
- 2. **Port Member:** Displays the members of this static trunk group.

regulor set		Jgregator monnator	
		System Priority	
	Group ID	Trunk.1 👻	
	LACP Work Ports	Disable 💌	
	Port.01 Port.02	< <add Remove>></add 	Port.05 A Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.13

Port Trunk—Aggregator Setting interface (two ports are added to the left field with LACP disable)

Port Trunk – Aggregator Information interface

State Activity

Having set up the LACP aggregator on the tab of Aggregator Setting, you can configure the state activity for the members of the LACP trunk group. You can tick or cancel the checkbox beside the state display. When you remove the tick mark to the port and click

Apply, the port state activity will change to **Passive**.

Active: The port automatically sends LACP protocol packets.

- Passive: The port does not automatically send LACP protocol packets, and responds only if it receives LACP protocol packets from the opposite device.
 - [NOTE] 1. A link having either two active LACP nodes or one active node can perform dynamic LACP trunk.
 - 2. **A link** having two passive LACP nodes will not perform dynamic LACP trunk because both ports are waiting for an LACP protocol packet from the opposite device.

PortLACP State ActivityPort.01N/APort.02N/APort.03N/APort.04N/APort.05N/APort.06N/A
Port.01N/APort.02N/APort.03N/APort.04N/APort.05N/APort.06N/A
Port.03 N/A Port.04 N/A Port.05 N/A Port.06 N/A
Port.05 N/A Port.06 N/A
Port.07 N/A Port.08 N/A
Port.09 N/A Port.10 N/A
Port.11 N/A Port.12 N/A
Port.13 N/A Port.14 N/A
Port.15 N/A Port.16 N/A
Port.17 N/A Port.18 N/A
Port.19 N/A Port.20 N/A
Port.21 N/A Port.22 N/A
Port.23 N/A Port.24 N/A
Port.25 N/A Port.26 N/A

Port Trunk - State Activity interface

Port Mirroring

The Port mirroring is a method for monitoring traffic in switched networks. Traffic through ports can be monitored by one specific port, which means traffic goes in or out **Monitored** (source) port will be duplicated into **Analysis** (destination) port.



Port Trunk – Port Mirroring interface

- Mode: Choose the type of being monitored packets. RX means only the received packets of the monitored port will be copied and sent to the analysis port. TX means only the transmitted packets of the monitored port will be copied and sent to the analysis port. Both RX/TX means both received & transmitted packets of the monitored port will be copied and sent to the analysis port.
- Analysis Port: There is only one port can be selected to be the analysis (destination) port for monitoring both RX and TX traffic which come from the source port. Users can connect the analysis port to LAN analyzer or Netxray.
- Monitored Port: Choose a port number to be monitored. Only one port can be monitored during the monitoring process.
- And then, click Apply

Rate Limiting

All the ports support packet ingress and egress rate control. For example, assume the wire speed of port 1 is 100Mbps; users can set its effective egress rate as 2Mbps, ingress rate as 1Mbps. The switch performs the ingress rate by packet counter to meet the specified rate.

- Inrate: Enter the port effective ingress rate (The default value is "0").
- **OutRate:** Enter the port effective egress rate (The default value is "0").

The rate range for port 1 to 24 is from 1 to 100 Mbps and the rate range for port 25, 26 is from 1 to 1000 Mbps. The zero means disabled.

Port		InRate	-	OutRate
Port.01	0	Mbps	0	Mbps
Port.02	0	Mbps	0	Mbps
Port.03	0	Mbps	0	Mbps
Port.04	0	Mbps	0	Mbps
Port.05	0	Mbps	0	Mbps
Port.06	0	Mbps	0	Mbps
Port.07	0	Mbps	0	Mbps
Port.08	0	Mbps	0	Mbps
Port.09	0	Mbps	0	Mbps
Port.10	0	Mbps	0	Mbps
Port.11	0	Mbps	0	Mbps
Port.12	0	Mbps	0	Mbps
Port.13	0	Mbps	0	Mbps
Port.14	0	Mbps	0	Mbps
Port.15	0	Mbps	0	Mbps
Port.16	0	Mbps	0	Mbps
Port.17	0	Mbps	0	Mbps
Port.18	0	Mbps	0	Mbps
Port.19	0	Mbps	0	Mbps
Port.20	0	Mbps	0	Mbps
Port.21	0	Mbps	0	Mbps
Port.22	0	Mbps	0	Mbps
Port.23	0	Mbps	0	Mbps
Port.24	0	Mbps	0	Mbps
Port.25	0	Mbps	0	Mbps
Dort 26	0	Mbps	0	Mbps

Rate Limiting interface

VLAN configuration

A Virtual LAN (VLAN) is a logical network grouping that limits the broadcast domain, which would allow you to isolate network traffic, so only the members of the same VLAN will receive traffic from the ones of the same VLAN. Basically, creating a VLAN from a switch is logically equivalent of reconnecting a group of network devices to another Layer 2 switch. However, all the network devices are still plugged into the same switch physically.

The switch supports **Port-based** and **802.1Q** (tagged-based) VLAN. The default configuration of VLAN operation mode is **Disable**.

VLAN Configuration
VLAN Operation Mode : Disable
Enable GVRP Protocol
Management Vlan ID :
Apply Please use Save Configuration to permanently save the updates.
VLAN NOT ENABLE

VLAN Configuration interface

VLAN configuration - Port-based VLAN

Packets can go among only members of the same VLAN group. Note all unselected ports are treated as belonging to another single VLAN. If the port-based VLAN enabled, the VLAN-tagging is ignored.

In order for an end station to send packets to different VLAN groups, it itself has to be either capable of tagging packets it sends with VLAN tags or attached to a VLAN-aware bridge that is capable of classifying and tagging the packet with different VLAN ID based on not only default PVID but also other information about the packet, such as the protocol.



VLAN – Port Based interface

Pull down the selection item and focus on Port Based then press (Apply) to set the V(LAN) Operation Mode in Port Based mode.

the VLAN Operation Mode in Port Based mode.

Click (Add) to add a new VLAN group.

VLAN Opera VLAN Opera Enable O Managemen	Configu ation Mode : Port GVRP Protocol Int Vlan ID : Apply Ination to perman	ently save the updates.
Group Name VLAN ID Port.07 Port.08 Port.09 Port.10 Port.11 Port.12	VLAN_1 1 Add	Port.03 Port.04 Port.05 Port.06
Port.13 Port.14 Port.15 Port.16 Port.17 Port.18	Remove Apply Help	

VLAN—Port Based Add interface

- Enter the group name and VLAN ID. Add the port number having selected into the right field to group these members to be a VLAN group or remove any of them listed in the right field from the VLAN.
- And then, click (Apply) to have the settings taken effect.
- You will see the VLAN displays.
| VLAN Configuration |
|--|
| VLAN Operation Mode : Port Based 💌
Enable GVRP Protocol
Management Vlan ID : |
| Apply
Please use Save Configuration to permanently save the updates. |
| VLAN_11 |
| Add Edit Delete Help
Please use Save Configuration to permanently save the updates. |

VLAN—Port Based Edit/Delete interface

- Use Delete to delete the VLAN.
- Use Edit to modify group name, VLAN ID, or add/remove the members of the existing VLAN group.

[NOTE] Remember to execute the "Save Configuration" action, otherwise the new configuration will lose when switch power off.

802.1Q VLAN

Virtual Local Area Network (VLAN) can be implemented on the switch to logically create different broadcast domain.

When the 802.1Q VLAN function is enabled, all ports on the switch belong to default VLAN of VID 1, which means they logically are regarded as members of the same broadcast domain. The valid VLAN ID is in the range of number between 1 and 4094. The amount of VLAN groups is up to 256 including default VLAN that cannot be deleted.

Each member port of 802.1Q is on either an Access Link (to be VLAN-tagged) or a Trunk Link (will not be VLAN-tagged). All frames into an Access Link carry no VLAN identification. Conversely, all frames into a Trunk Link are previously VLAN-tagged. Besides, there is the third mode—Hybrid. A Hybrid Link can carry both VLAN-tagged frames and untagged frames. A single port is supposed to belong to one VLAN group, except when it is on a Trunk/Hybrid Link.

The technique of 802.1Q tagging inserts a 4-byte tag, including VLAN ID of the destination port—PVID, in the frame. With the combination of Access/Trunk/Hybrid Links, the communication across switches also can make the packet sent through tagged and untagged ports.

802.1Q Configuration

- Pull down the selection item and focus on 802.1Q then press (Apply) to set the VLAN Operation Mode in 802.1Q mode.
- Enable GVRP Protocol: GVRP (GARP VLAN Registration Protocol) is a protocol that facilitates control of virtual local area networks (VLANs) within a larger network. GVRP conforms to the IEEE 802.1Q specification, which defines a method of tagging frames with VLAN configuration data. This allows network devices to dynamically exchange VLAN configuration information with other devices. For example, having enabled GVRP on two switches, they are able to automatically exchange the information of their VLAN database. Therefore, the user doesn't need to manually configure whether the link is trunk or hybrid, the packets belonging to the same VLAN can communicate across switches. Tick this checkbox to enable GVRP protocol. This checkbox is available while the VLAN Operation Mode is in 802.1Q mode.
- Management VLAN ID: Only when the VLAN members, whose Untagged VID (PVID) equals to the value in this column, will have the permission to access the switch. The default value is '0' that means this limit is not enabled (all members in different VLANs can access this switch).
- Select the port you want to configure.
- Link Type: There are 3 types of link type.
 - Access Link: A segment which provides the link path for one or more stations to the VLAN-aware device. An Access Port (untagged port), connected to the access link, has an untagged VID (also called PVID). After an untagged frame gets into the access port, the switch will insert a four-byte tag in the frame. The contents of the last 12-bit of the tag is untagged VID. When this frame is sent out through any of the access port of the same PVID, the switch will remove the tag from the frame to recover it to what it was. Those ports of the same untagged VID are regarded as the same VLAN group members.

Note: Because the access port doesn't have an understanding of tagged frame, the column field of Tagged VID is not available.

Trunk Link: A segment which provides the link path for one or more VLANaware devices (switches). A Trunk Port, connected to the trunk link, has an understanding of tagged frame, which is used for the communication among VLANs across switches. Which frames of the specified VIDs will be forwarded depends on the values filled in the Tagged VID column field. Please insert a comma between two VIDs.

Note:

- 1. A trunk port doesn't insert tag into an untagged frame, and therefore the untagged VID column field is not available.
- 2. It's not necessary to type '1' in the tagged VID. The trunk port will forward the frames of VLAN 1.
- 3. The trunk port has to be connected to a trunk/hybrid port of the other switch. Both the tagged VID of the two ports have to be the same.
 - Hybrid Link: A segment which consists of Access and Trunk links. The hybrid port has both the features of access and trunk ports. A hybrid port has a PVID belonging to a particular VLAN, and it also forwards the specified tagged-frames for the purpose of VLAN communication across switches.

Note:

- 1. It's not necessary to type '1' in the tagged VID. The hybrid port will forward the frames of VLAN 1.
- 2. The trunk port has to be connected to a trunk/hybrid port of the other switch. Both the tagged VID of the two ports have to be the same.
- Untagged VID: This column field is available when Link Type is set as Access Link and Hybrid Link. Assign a number in the range between 1 an 4094.
- Tagged VID: This column field is available when Link Type is set as Trunk Link and Hybrid Link. Assign a number in the range between 1 an 4094.

- Click (Apply) to have the configuration take effect.
- You can see the link type, untagged VID, and tagged VID information of each port in the table below on the screen.

	VLAN	Configura	ation
	VLAN Op	eration Mode : 802.1Q	
	Enab	le GVRP Protocol	
	La crist		
	IManager	ment vian ID ; U	
		Apply	
	Please use Save Cont	iguration to permanently	save the updates.
	802.1Q Configuration		Group Configuration
-	and the second second		
	Port Link Typ	e Untagged Vid Ta	gged Vid
	Port.03 💌 Access I	Link 🜱 1	
	The second second		
		and the second s	
		Apply Help	
	Please use Save Cont	iguration to permanently	save the updates.
Dort	Link Tuno	Untagged Vid	Tangod Vid
Port 03	Access Link		lagged via
Port 04	Access Link	1	
Port.05	Hybrid Link	1	10.
Port.06	Access Link	1	
Port.07	Access Link	1	
Port.08	Trunk Link	1	12,13,14,
Port.09	Access Link	1	
Port.10	Access Link	1	
Port.11	Access Link	1	
Port.12	Access Link	1	
Port.13	Access Link	1	
Port.14	Access Link	1	
Port.15	Access Link	1	
Port.16	Access Link	1	
Port.17	Access Link	1	
Port.18	Access Link	1	
Port.19	Access Link	1	
Port.20	Access Link	1	
Port.21	Access Link	1	
Port.22	Access Link	1	
Port.23	Access Link	1	
Port.24	Access Link	1	
Port.25	Access Link	1	
Port.26	Access Link	1	
Trunk01	Access Link	1	

802.1Q VLAN interface

Group Configuration

Edit the existing VLAN Group.

- Select the VLAN group in the table list.
- Click

VLAN Operation M DEnable GVRP P Management Vlar	Nade : 802.1Q
Please use Save Configuration 802.1Q Configuration	Apply to permanently save the updates. Group Configuration
Default VLAN VLAN VLAN VLAN	$ \begin{bmatrix} 1 \\ 10 \\ $

Group Configuration interface

■ You can modify the VLAN group name and VLAN ID.

VLAN Config	uration
VLAN Operation Mode : 80)2.1Q
Management Vlan ID : 0	
Please use Save Configuration to perma	mently save the updates.
802.1Q Configuration	Group Configuration
Group Name VLAN_10	
VLAN ID 10	
Apply	
Please use Save Configuration to perma	mently save the updates.
Group Configuration	interface
Click Apply.	

Rapid Spanning Tree

The Rapid Spanning Tree Protocol (RSTP) is an evolution of the Spanning Tree Protocol and provides for faster spanning tree convergence after a topology change. The system also supports STP and the system will auto-detect the connected device that is running STP or RSTP protocol.

RSTP - System Configuration

- The user can view spanning tree information of Root Bridge.
- The user can modify RSTP state. After modification, click (Apply
 - RSTP mode: The user must enable the RSTP function first before configuring the related parameters.
 - Priority (0-61440): The switch with the lowest value has the highest priority and is selected as the root. If the value is changed, the user must reboot the switch. The value must be a multiple of 4096 according to the protocol standard rule.
 - Max Age (6-40): The number of seconds a switch waits without receiving Spanning-tree Protocol configuration messages before attempting a reconfiguration. Enter a value between 6 through 40.
 - Hello Time (1-10): The time that controls the switch to send out the BPDU packet to check RSTP current status. Enter a value between 1 through 10.
 - Forward Delay Time (4-30): The number of seconds a port waits before changing from its Rapid Spanning-Tree Protocol learning and listening states to the forwarding state. Enter a value between 4 through 30.
- [NOTE] Follow the rule as below to configure the MAX Age, Hello Time, and Forward Delay Time.
 2 x (Forward Delay Time value -1) > = Max Age value >= 2 x (Hello Time value +1)

ole 768 0 5 vual to the Ma
768 0 5
768 0 5
0 5
5
5 wal to the Ma
ual to the Ma
the updates,
1

RSTP System Configuration interface

RSTP—Port Configuration

You can configure path cost and priority of every port.

- Select the port in the port column field.
- Path Cost: The cost of the path to the other bridge from this transmitting bridge at the specified port. Enter a number 1 through 200,000,000.
- Priority: Decide which port should be blocked by priority in LAN. Enter a number 0 through 240 (the port of the highest value will be blocked). The value of priority must be the multiple of 16.
- Admin P2P: Some of the rapid state transactions that are possible within RSTP are dependent upon whether the port concerned can only be connected to exactly one other bridge (i.e. it is served by a point-to-point LAN segment), or can be connected to two or more bridges (i.e. it is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively. True is P2P enabling. False is P2P disabling.
- Admin Edge: The port directly connected to end stations won't create bridging loop in the network. To configure the port as an edge port, set the port to "True" status.
- Admin Non Stp: The port includes the STP mathematic calculation. True is not including STP mathematic calculation. False is including the STP mathematic calculation.
- Click Apply.

	System Co	onfiguration			Port	Configuratio	n
	P	ath Cost	Priority				
Por	(1-2	000000000) (0-240) Admin	P2P Admin	Edge Adm	in Non STF
Port.01 Port.02 Port.03 Port.04 Port.05	*	20000(128	Auto	* true	M f	alse 💌
		priorit	y must	be a m	ultiple of	16	
			Anni	у на	In		
			CEPP				
	-		-		and the first		
	Flease	use Save Ct	onnguratio	on to pern	nanently save	the update	
			RSTP	Port St	atus		
Port	Path	Port	Oper	Oper	STP	State	Role
Port.01	200000	128	True	True	False	Disabled	Disabled
Port 02	200000	128	True	True	False	Forwarding	Designate
Port 03	200000	128	True	True	False	Disabled	Disabled
Port 04	200000	128	True	True	Falco	Disabled	Disabled
					E GLOG	Disamen	Usanied
Port.05	200000	128	True	True	False	Disabled	Disabled
Port.05 Port.06	200000	128 128	True True	True True	False	Disabled Disabled	Disabled Disabled Disabled
Port.05 Port.06 Port.07	200000 200000 200000	128 128 128	True True True	True True True	False False False	Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08	200000 200000 200000 200000	128 128 128 128	True True True True	True True True True	False False False False False	Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09	200000 200000 200000 200000 200000	128 128 128 128 128	True True True True True	True True True True True	False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10	200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128	True True True True True True True	True True True True True True	False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11	200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True	False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12	200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.09 Port.09 Port.10 Port.11 Port.12 Port.13	200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.13 Port.14	200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.13 Port.14 Port.15	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.13 Port.14 Port.15 Port.15	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.13 Port.14 Port.15 Port.16 Port.16	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.08 Port.10 Port.10 Port.11 Port.12 Port.14 Port.14 Port.15 Port.15 Port.17 Port.18	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.14 Port.14 Port.15 Port.16 Port.17 Port.18 Port.18	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.10 Port.10 Port.12 Port.12 Port.13 Port.14 Port.15 Port.16 Port.17 Port.18 Port.19 Port.19	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False False False False False False False False False False False False False False False False False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.12 Port.12 Port.15 Port.15 Port.16 Port.18 Port.19 Port.19 Port.20 Port.20	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Uisabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.12 Port.13 Port.13 Port.15 Port.15 Port.16 Port.17 Port.19 Port.20 Port.21 Port.21	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Uisabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.09 Port.10 Port.11 Port.12 Port.13 Port.13 Port.14 Port.15 Port.16 Port.17 Port.18 Port.19 Port.20 Port.21 Port.22 Port.22 Port.22	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False	Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Uisabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.10 Port.10 Port.12 Port.12 Port.13 Port.13 Port.14 Port.15 Port.14 Port.15 Port.16 Port.17 Port.18 Port.20 Port.21 Port.22 Port.23 Port.2	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False	Disabled Disabled	Disabled Disabled
Port.05 Port.06 Port.07 Port.08 Port.10 Port.10 Port.12 Port.12 Port.13 Port.14 Port.13 Port.14 Port.15 Port.16 Port.16 Port.17 Port.20 Port.21 Port.22 Port.23 Port.23 Port.24 Port.24 Port.24 Port.24 Port.24	200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000 200000	128 128 128 128 128 128 128 128 128 128	True True True True True True True True	True True True True True True True True	False False </td <td>Disabled Disabled</td> <td>Disabled Disabled</td>	Disabled Disabled	Disabled Disabled

RSTP Port Configuration interface

SNMP Configuration

Simple Network Management Protocol (SNMP) is the protocol developed to manage nodes (servers, workstations, routers, switches and hubs etc.) on an IP network. SNMP enables network administrators to manage network performance, find and solve network problems, and plan for network growth. Network management systems learn of problems by receiving traps or change notices from network devices implementing SNMP.

System Configuration

Community Strings

Here you can define the new community string set and remove the unwanted community string.

- **String:** Fill the name string.
- RO: Read only. Enables requests accompanied by this community string to display MIB-object information.
- RW: Read write. Enables requests accompanied by this community string to display MIB-object information and to set MIB objects.
- > Click (Add).
- To remove the community string, select the community string that you have defined and click Remove. You cannot edit the name of the default community string set.

■ Agent Mode: Select the SNMP version that you want to use and then click

Change to switch to the selected SNMP version mode. The default value is

'SNMP v1/v2c only'

System Configuration	Trap Configuration	SNMPv3 Configuration
Agent Mo	Com SNMP V1/V2C only SNMP V1/V2C only SNMP V1/V2C only SNMP V3 only SNMP V1/V2C/V3	Change Add
publicRO privateRW	String :	ORW

SNMP System Configuration interface

Trap Configuration

A trap manager is a management station that receives the trap messages generated by the switch. If no trap manager is defined, no traps will be issued. Create a trap manager by entering the IP address of the station and a community string. To define a management station as a trap manager, assign an IP address, enter the SNMP community strings, and select the SNMP trap version.

- IP Address: Enter the IP address of the trap manager.
- **Community:** Enter the community string.
- **Trap Version:** Select the SNMP trap version type—v1 or v2c.
- Click
- To remove the community string, select the community string listed in the current managers field and click Remove.

stem Configuration	Trap Configuration	SNMPv3 Configuration
	Trap Managers	
Current Managers :	nove New Manager : Ad	d
(none)	IP Address : Community : Trap version:	0 v2c

Trap Managers interface

SNMPV3 Configuration

Configure the SNMP V3 function.

Context Table

Configure SNMP v3 context table. Assign the context name of context table. Click



User Profile

Configure SNMP v3 user table..

- **User ID:** Set up the user name.
- Authentication Password: Set up the authentication password.
- **Privacy Password:** Set up the private password.
- Click Add to add

b to add the context name.

Click Remove the unwanted context name.

SNMP - S	SNMPv3 Configu	ration
System Configuration	Trap Configuration SN	MPv3 Configuration
	Context Table	
Context Name :		Apply
	User Table	
Current User Profiles :	New User Profile :	
(none)	User ID:	
	Authentication Password:	
	Privacy Password:	
	Convertable	
\bigcirc	Group Lable	
Current Group content :	New Group Table:	
(none)	Security Name (User ID):	
	Group Name:	
and the second	Access Table	
Current Access Tables :	New Access Table :	
(none)	Context Prefix:	
	Group Name:	
	Security Level:	○ NoAuthNoPriv. ○ AuthNoPriv. ○ AuthPriv.
	Context Match Rule	O Exact O Prefix
	Read View Name:	
N. //	Write View Name:	
	Notify View Name:	
	MIBView Table	
Current MIBTables :	New MIBView Table :	
(none)	View Name:	

SNMP V3 configuration interface

Group Table

Configure SNMP v3 group table.

- Security Name (User ID): Assign the user name that you have set up in user table.
- **Group Name:** Set up the group name.
- Click (Add) to add the context name.
- Click (Remove) to remove the unwanted context name.

Access Table

Configure SNMP v3 access table.

- **Context Prefix:** Set up the context name.
- **Group Name:** Set up the group.
- **Security Level:** Set up the access level.
- **Context Match Rule:** Select the context match rule.
- **Read View Name:** Set up the read view.
- Write View Name: Set up the write view.
- Notify View Name: Set up the notify view.
- Click (Add) to add the context name.
- Click Remove to remove the unwanted context name.

MIBview Table

Configure MIB view table.

- ViewName: Set up the name.
- **Sub-Oid Tree:** Fill the Sub OID.
- **Type:** Select the type—excluded or included.

- Click (Add) to add the context name.
- Click (Remove) to remove the unwanted context name.

QoS Configuration

You can configure QoS mode, 802.1p priority [7-0] setting, Static Port Ingress Priority setting and TOS setting.

QoS Policy and Priority Type

- **Qos Mode:** Select the QoS policy rule.
 - > **Disable QoS Priority:** The default status of Qos Priority is disabled.
 - High Empty Then Low: When all the high priority packets are empty in queue, low priority packets will be processed then.
 - Highest:SecHigh:SecLow:Lowest:8:4:2:1: The switch will follow 8:4:2:1 rate to process priority queue from Highest to lowest queue. For example: the system will process 80 % highest queue traffic, 40 % SecHigh queue traffic, 20 % SecLow queue traffic, and 10 % Lowest queue traffic at the same time. And the traffic in the Lowest Priority queue are not transmitted until all Highest, SecHigh, and SecLow traffic are serviced.
 - Highest:SecHigh:SecLow:Lowest:15:7:3:1: The process order is in compliance with the transfer rate of 15:7:3:1.
 - Highest:SecHigh:SecLow:Lowest:15:10:5:1: The process order is in compliance with the transfer rate of 15:10:5:1.
- 802.1p priority [7-0]: Configure per priority level. Each priority has 4 priority levels— Highest, SecHigh, SecLow, and Lowest.
- **Default Ingress Port Priority Mapping:** The port ingress level is from 0 to 7.
- TOS/DSCP Priority Mapping: The system provides 0 ~ 63 TOS priority level. Each level has 8 priorities—0 ~ 7. The default value is "0" priority for each level. When the IP packet is received, the system will check the TOS level value in the IP packet that

has received. For example, user set the TOS level 25 as 0. The port 1 is following the TOS priority policy only. When the port 1 packet received, the system will check the TOS value of the received IP packet. If the TOS value of received IP packet is 25 (priority = 0), and then the packet priority will have highest priority.

	Q	os Mode:	Disable	QoS Prio	rity		14		
			Disable (os Prio	rity				
102.1p P	riority:		High Emp Highest:	High Empty Then Low Highest:SecHigh:SecLow:Lowest = 8:4:2:1				-	0
Lower	Lowest	Low	Highest:	SecHigh:	SecLow:Lov	vest =	15:7:3:1	L	U.
10 11 10 24	LOWCOC	EST	[Highest.	sechigit	Sectow.Lov	vest -	13.10.3.1	C.S.A.	110 00 00
	Default I	ngress Po	ort Priority	y Mappi	ng:	_		1	160
	Port.01	0	Port.09	0	Port.17	ū	Port.25	Ø	-
	Port.02	ū	Port.10	0	Port.18	Ð	Port.26	0	
	Port.03	0	Port.11	0	Port.19	0			
	Port.04	I	Port.12	D	Port.20	D		1	11.1
	Port.05	0	Port.13	0	Port.21	0			N
	Port.06	ū -	Port.14	Û	Port.22	0			
	Port.07	0	Port.15	0	Port.23	0			
	Port.08	<u>n</u>	Port.16	D	Port.24	D			
	TOSIDS	D Driorit	v Manning					-	100
	TOSO		TOS16	0	TOS32	0	TOS48	0	120
	TOS1	0	TOS17	a	TOS33	0	TOS49	0	
	TOS2	0	TOS18	0	TOS34	0	TOS50	0	
	TOS3	U	TOS19	a	TOS35	0	TOS51	D	
	TOS4	0 ×	TOS20	0	TOS36	0	TOS52	0	
	TOS5	0	TOS21	<u>a</u>	TOS37	Û	TOS53	0	
	TOS6	D	TOS22	0	TOS38	Ū.	TOS54	0	
	TOS7	П	TOS23	0	TOS39	0	TOS55	D	
	TOS8	D	TOS24	0	TOS40	0	TOS56	0	
	TOS9	0	TOS25	ū	TOS41	0	TOS57	0	
	TOS10	0	TOS26	0	TOS42	0	TOS58	0	
	TOS11	U	TOS27	D	TOS43	C	TOS59	D	
	TOS12	0 ×	TOS28	0	TOS44	0	TOS60	0	1
	TOS13	0	TOS29	â	TOS45	Ô	TOS61	0	
	TOS14	D	TOS30	0	TOS46	0	TOS62	0	
	TOCIE		TOCOL		TOCAT	0	TOCCO	0	

QoS Configuration interface

IGMP Configuration

The Internet Group Management Protocol (IGMP) is an internal protocol of the Internet Protocol (IP) suite. IP manages multicast traffic by using switches, routers, and hosts that support IGMP. Enabling IGMP allows the ports to detect IGMP queries, report packets, and manage IP multicast traffic through the switch. IGMP has three fundamental types of message shown as follows:

Message	Description
	A message sent from the querier (IGMP router or switch)
Query	asking for a response from each host belonging to the
	multicast group.
Report	A message sent by a host to the querier to indicate that the host wants to be or is a member of a given group indicated in the report message.
Leave Group	A message sent by a host to the querier to indicate that the host has quit being a member of a specific multicast group.

The switch supports IP multicast. You can enable IGMP protocol via setting the IGMP Configuration page to see the IGMP snooping information. IP multicast addresses are in the range of 224.0.0.0 through 239.255.255.255.

- **IGMP Protocol:** Enable or disable the IGMP protocol.
- IGMP Query: Select the IGMP query function as Enable or Auto to set the switch as a querier for IGMP version 2 multicast networks.

Click Apply.

옷	IGMP (Config	uration	
1	IP Address	VLAN ID	Member Port	
10	GMP Protoc	ol: Ei	nable ⊻	
]	GMP Query	/:	uto 💙	
Last Me	mber Quer	y Count: 2		
Last Mer	nber Query	Interval: 10	tenths of a	second
	-	Apply Help		
Please u	ise Save Configu	uration to perma	nently save the up	idates.

IGMP Configuration interface

LLDP Configuration

LLDP (Link Layer Discovery Protocol) function allows the switch to advertise its information to other nodes on the network and store the information it discovers.

- **LLDP Protocol:** Disable or enable LLDP function.
- **LLDP Interval:** Set the interval of learning the information time in second.



LLDP Configuration interface

X-Ring

X-Ring provides a faster redundant recovery than Spanning Tree topology. The action is similar to STP or RSTP, but the algorithms between them are not the same.

In the X-Ring topology, every switch should be enabled with X-Ring function and two ports should be assigned as the member ports in the ring. Only one switch in the X-Ring group would be set as the master switch that one of its two member ports would be blocked, called backup port, and another port is called working port. Other switches in the X-Ring group are called working switches and their two member ports are called working ports. When the failure of network connection occurs, the backup port of the master switch (Ring Master) will automatically become a working port to recover from the failure.

The switch supports the function and interface for setting the switch as the ring master or not. The ring master can negotiate and place command to other switches in the X-Ring group. If there are 2 or more switches in master mode, the software will select the switch with lowest MAC address number as the ring master. The X-Ring master ring mode can be enabled by setting the X-Ring configuration interface. Also, the user can identify whether the switch is the ring master by checking the R.M. LED indicator on the panel of the switch.

The system also supports the **Couple Ring** that can connect 2 or more X-Ring group for the redundant backup function; **Dual Homing** function that can prevent connection lose between X-Ring group and upper level/core switch.

- Enable Ring: To enable the X-Ring function, tick the checkbox beside the Enable Ring string label. If this checkbox is not ticked, all the ring functions are unavailable.
 - Enable Ring Master: Tick the checkbox to enable this switch to be the ring master.
 - 1st & 2nd Ring Ports: Pull down the selection menu to assign the ports as the member ports. 1st Ring Port is the working port and 2nd Ring Port is the

backup port. When 1st **Ring Port** fails, the system will automatically upgrade the 2nd **Ring Port** to be the working port.

- Enable Couple Ring: To enable the coupe ring function, tick the checkbox beside the Enable Couple Ring string label.
 - Couple Port: Assign the member port which is connected to the other ring group.
 - Control Port: When the Enable Couple Ring checkbox is ticked, you have to assign the control port to form a couple-ring group between the two X-rings.
- Enable Dual Homing: Set up one of the ports on the switch to be the Dual Homing port. For a switch, there is only one Dual Homing port. Dual Homing function only works when the X-Ring function enabled.
 - > Homing Port: Assign a port which is used to be the dual homing port.
- And then, click (Apply) to have the configuration taken effect.

Enable Ring Master Ist Ring Port Port.01 Port.02 Enable Couple Ring Coupling Port Port.03 Control Port Port.04 Sachla Deck Huming
1st Ring Port Port.01 × 2nd Ring Port Port.02 × Enable Couple Ring Port.03 × Coupling Port Port.03 × Control Port Port.04 ×
2nd Ring Port Port.02 ✓ Enable Couple Ring Port.03 ✓ Coupling Port Port.03 ✓ Control Port Port.04 ✓
Enable Couple Ring Coupling Port Port.03 ~ Control Port Port.04 ~ Sachle Dual Haming Port 05 ~
Coupling Port Port.03 ** Control Port Port.04 **
Control Port Port.04 V
Trackle Duct Houses Doct OF w
_ Enable Dual Homing Purc.05
ing Port 2nd Ring Port Coupling Port Control Port

X-ring Interface

- [NOTE] 1. When the X-Ring function enabled, the user must disable the RSTP. The X-Ring function and RSTP function cannot exist on a switch at the same time.
 - 2. Remember to execute the "Save Configuration" action, otherwise the new

Security

In this section, you can configure the 802.1x and MAC address table.

802.1X/Radius Configuration

802.1x is an IEEE authentication specification which prevents the client from connecting to a wireless access point or wired switch until it provides authority, like the user name and password that are verified by an authentication server (such as RADIUS server).

System Configuration

After enabling the IEEE 802.1X function, you can configure the parameters of this function.

- IEEE 802.1x Protocol: Enable or disable 802.1x protocol.
- Radius Server IP: Assign the RADIUS Server IP address.
- Server Port: Set the UDP destination port for authentication requests to the specified RADIUS Server.
- Accounting Port: Set the UDP destination port for accounting requests to the specified RADIUS Server.
- Shared Key: Set an encryption key for using during authentication sessions with the specified RADIUS server. This key must match the encryption key used on the RADIUS Server.
- NAS, Identifier: Set the identifier for the RADIUS client.
- Click Apply

stem Configuration	Po	rt Configuration	Misc Configuration
802.1x P	rotocol	Enable 💌	1
Radius Se	erver IP	192.168.10.45	
Server	Port	1812	
Accounti	ng Port	1813	
Shared	l Key	12345678	
NAS, Ide	entifier	NAS_L2_SWITCH	
NAS, Ide	entimer	INA5_L2_SWITCH	

802.1x System Configuration interface

802.1x Per Port Configuration

You can configure the 802.1x authentication state for each port. The state provides Disable, Accept, Reject, and Authorize.

- **Reject:** The specified port is required to be held in the unauthorized state.
- Accept: The specified port is required to be held in the Authorized state.
- Authorized: The specified port is set to the Authorized or Unauthorized state in accordance with the outcome of an authentication exchange between the Supplicant and the authentication server.
- Disable: When disabled, the specified port works without complying with 802.1x protocol.
- Click Apply.

802.1x/R	adius	- Port Conf	iguration
System Configuration	Port	Configuration	Misc Configuration
	Port	State	
	Port.01 A Port.02 Port.03 Port.04 Port.05	Authorize Reject Accept Authorize Disable	
Please use	Ap Save Configurat Port	ply Help tion to permanently save Authorization	the updates
6 M	Port	State	1
	Port.01	Disable	
	Port.02	Disable	
	Port.03	Disable	
	Port.04	Disable	
100	Port.05	Disable	
	Port.06	Disable	
	Port.07	Disable	
	Port.08	Disable	
	Port.09	Disable	
110	Port.10	Disable	
	Port.11	Disable	
	Port.12	Disable	
	Port.13	Disable	11
	Port.14	Disable	
	Port.15	Disable	
N. N.	Port.16	Disable	and the second sec
1.1.1	Port.17	Disable	
A 10 Dec. 20	Port.18	Disable	
	Port.19	Disable	
	Port.20	Disable	
	Port.21	Disable	
	Port.22	Disable	
	Port.23	Disable	
	Port.24	Disable	
	Port.25	Disable	

802.1x Per Port Setting interface

Misc Configuration

- Quiet Period: Used to define periods of time during which it will not attempt to acquire a supplicant (default time is 60 seconds)
- TX Period: Used to determine when an EAPOL PDU is to be transmitted (default value is 30 seconds).
- **Supplicant Timeout:** Used to determine timeout conditions in the exchanges

between the supplicant and authentication server (default value is 30 seconds).

- Server Timeout: Used to determine timeout conditions in the exchanges between the authenticator and authentication server (Default value is 30 seconds).
- Max Requests: Used to determine the number of reauthentication attempts that are permitted before the specific port becomes unauthorized (default value is 2 times).
- Reauth Period: Used to determine a nonzero number of seconds between periodic reauthentication of the supplications (the default value is 3,600 seconds).
- Click Apply.

System Configuration	Port Configuration	Misc C	onfiguration
	Quiet Period	60	
	Tx Period	30	
	Supplicant Timeout	30	
	Server Timeout	30	
	Max Requests	2	
1	Re-autheticate Period	3600	

802.1x Misc Configuration interface

MAC Address Table

Use the MAC address table to ensure the port security.

Static MAC Address

You can add a static MAC address; it remains in the switch's address table, regardless of whether the device is physically connected to the switch. This saves the switch from having to re-learn a device's MAC address when the disconnected or powered-off device is active on the network again. You can add / modify / delete a static MAC address.

Add the Static MAC Address

You can add static MAC address in the switch MAC table in here.

- MAC Address: Enter the MAC address of the port that should permanently forward traffic, regardless of the device network activity.
- **Port No.:** Pull down the selection menu to select the port number.
- Click Add
- If you want to delete the MAC address from filtering table, select the MAC address and click Delete.

MAC Address	Port	VLAN ID	W C
0022FFDD0011 00BBCCDDEE11	Port.03 Port.03	1	
MAC Addre	oo11223344		
Port No.	Port.03 💌		
VI ANI TO	10		

Static MAC Addresses interface

MAC Filtering

By filtering MAC address, the switch can easily filter the pre-configured MAC address and reduce the un-safety. You can add and delete filtering MAC address.

tatic MAC Addresses	MAC Filtering	All Mac Addresses	Multicast Filtering
	MAC Address	VLAN ID	
	001122334455 001B38E5841A	<u>1</u>	
	MAC Address		
	VLAN ID		

MAC Filtering interface

- MAC Address: Enter the MAC address that you want to filter.
- Click
- If you want to delete the MAC address from the filtering table, select the MAC

address and click Delete

All MAC Addresses

You can view the port that connected device's MAC address and the related devices' MAC address.

- Select the port.
- The selected port of static & dynamic MAC address information will be displayed in here.
- Click Clear to clear the current port static MAC address information on screen.



All MAC Address interface

MAC Address Table—Multicast Filtering

Multicasts are similar to broadcasts, they are sent to all end stations on a LAN or VLAN. Multicast filtering is the system by which end stations only receive multicast traffic if they register to join specific multicast groups. With multicast filtering, network devices only forward multicast traffic to the ports that are connected to registered end stations.

- IP Address: Assign a multicast group IP address in the range of 224.0.0.0 ~ 239.255.255.255.
- Member Ports: Tick the check box beside the port number to include them as the member ports in the specific multicast group IP address.
- Click Clear to clear the current port static MAC address information on screen.

tatic MAC Addresses	MAC Filtering	All Mac Addresses	Multicast Filtering
IP Address _	VLAN ID	Member Port	and the second
192.168.01 192.168.01	0.056 10 0.055 10)1****06********************************	****** 9***23***
IP A	ddress		
VLA	N ID		
	Port.0	1 🗌 Port.02 🗌 Port.03 🗌 🖡	Port.04
	D Port.0	15 🗌 Port.06 🗌 Port.07 🗌 F	Port.08
			Port 12
			FOIC.12
Men	nber Ports [] Port.)	.3 Port.14 Port.15 F	Port.16
1 - C	Port.1	.7 🗌 Port.18 🗌 Port.19 🗌 🖡	Port.20
	Port.2	1 Port.22 Port.23 F	Port.24
	Port 2	25 Port 26	

Multicast Filtering interface

Access Control List

- **Group Id:** Type in the Group ID from 1 to 255.
- Action: Permit and Deny.
- VLAN: Select any or a particular VID.
- Packet type: Select packet type—IPv4 or Non-IPv4
- Src IP Address: Select any or assign an IP address with Subnet Mask for source IP address.
- Dst IP Address: Select any or assign an IP address with Subnet Mask for destination IP address.
- **Ether Type:** Pull down the select menu for Any, ARP or IPX.
- IP Fragment: Set this item as to whether the fragment is checked or not.
- L4 Protocol: Assign the L4 protocol from among ICMP(1), IGMP(2), TCP or UDP.
- **Current List:** Displays the current list information.

Group Id	(1~255)	
Action	Permit 🛩	
VLAN	⊗Any ○VID 1 (1~4094)	
Packet Type	⑧ IPv4	O Non-IPv4
Src IP Address	⊙ Any ○ IP 0.0.0.0 Mask 255.255.255.255	Ether Type Any VType#(0x)
Dst IP Address	⊙ Any ○ IP 0.0.0.0 Mask 255.255.255.255	
IP Fragment	Uncheck 😪	
L4 Protocol	 Any Protocol#: TCP Any Port#: UDP Any Port#: 	
Current List		

Access Control List interface

Factory Default

Reset switch to default configuration. Click (Reset) to reset all configurations to the default value.



Factory Default interface

Save Configuration

Save all configurations that you have made in the system. To ensure the all configuration



save to save the all configuration to the flash memory.



Save Configuration interface

System Reboot

Reboot the switch in software reset. Click (Reboot) to reboot the system.



System Reboot interface

Incorrect connections

The switch port can automatically detect straight or crossover cable when you link switch with other Ethernet device. For the RJ45 connector, the user should use correct UTP/STP cable. The link will fail if the RJ45 connector is not correctly pinned on right position. For fiber connection, please notice that fiber cable mode and fiber transceiver should match.

Faulty or loose cables

Look for loose or obviously faulty connections. If they appear to be OK, make sure the connections are snug. IF that does not correct the problem, try a different cable.

Non-standard cables

Non-standard and miss-wired cables may cause numerous network collisions and other network problem, and can seriously impair network performance. A category 5e/6-cable tester is a recommended tool for network installation.

RJ45 ports: Use unshielded twisted-pair (UTP) or shielded twisted-pair (STP) cable for RJ45 connections. Also be sure that the length of any twisted-pair connection does not exceed 100 meters (328 feet). Gigabit port should use Cat-5e or cat-6 cable for 1000Mbps connections.

Improper Network Topologies

It is important to make sure that you have a valid network topology. Common topology faults include excessive cable length and too many repeaters (hubs) between end nodes. In addition, you should make sure that your network topology contains no data path loops. Between any two end nodes, there should be only one active cabling path at any time.

Data path loops will cause broadcast storms that will severely impact your network performance.

Diagnosing LED Indicators

To assist in identifying problems, the Switch can be easily monitored through panel indicators, which describe common problems the user may encounter and where the user can find possible solutions.

IF the power indicator does not light on when the power cord is plugged in, you may have a problem with power outlet, or power cord. However, if the Switch powers off after running for a while check for loose power connections, power losses or surges at power outlet. IF you still cannot resolve the problem, contact your local dealer for assistance.

RJ45 ports

The UTP/STP ports will automatically sense for Fast Ethernet (10/100Base-TX connections), or Gigabit Ethernet (10/100/1000Base-T connections). Auto MDI/MDIX means that the switch can connect to another switch or workstation without changing straight through or crossover cabling. See the figures below for straight through and crossover cable schematic.

10 /100BASE-TX Pin outs

With10/100BASE-TX cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 for receiving data.

■ RJ45 Pin Assignments

Pin Number	Assignment
1	Tx+
2	Tx-
3	Rx+
6	Rx-

[NOTE] "+" and "-" signs represent the polarity of the wires that make up each wire pair.
The table below shows the 10/100BASE-TX MDI and MDI-X port pin outs.

Pin Number	MDI-X Signal Name	MDI Signal Name
1	Receive Data plus (RD+)	Transmit Data plus (TD+)
2	Receive Data minus (RD-)	Transmit Data minus (TD-)
3	Transmit Data plus (TD+)	Receive Data plus (RD+)
6	Transmit Data minus (TD-)	Receive Data minus (RD-)

10/100Base-TX Cable Schematic

The following two figures show the 10/100Base-TX cable schematic.





Cross over cable schematic

10/100/1000Base-TX Pin outs

The following figure shows the 10/100/1000 Ethernet RJ45 pin outs.



10/100/1000Base-TX Cable Schematic



Straight through cables schematic



Cross over cables schematic

Commands Set List

User EXEC	Е
Privileged EXEC	Ρ
Global configuration	G
VLAN database	V
Interface configuration	I

System Commands Set

Netstar Commands	Level	Description	Example
show config	E	Show switch	switch> show config
		configuration	
show terminal	Р	Show console	switch# show terminal
		information	
write memory	G	Save user	switch# write memory
		configuration into	
		permanent memory	
		(flash rom)	
system name	G	Configure system	switch(config)#system name xxx
[System Name]		name	
system location	G	Set switch system	switch(config)#system location
[System Location]		location string	ххх
system description	G	Set switch system	switch(config)#system
[System Description]		description string	description xxx
system contact	G	Set switch system	switch(config)#system contact
[System Contact]		contact window string	ххх
show system-info	E	Show system	switch> show system-info
		information	

ip address	G	Configure the IP	switch(config)#ip address
[lp-address] [Subnet-		address of switch	192.168.1.1 255.255.255.0
mask] [Gateway]			192.168.1.254
ip dhcp	G	Enable DHCP client	switch(config)# ip dhcp
		function of switch	
show ip	Р	Show IP information of	switch# show ip
		switch	
no ip dhcp	G	Disable DHCP client	switch(config)# no ip dhcp
		function of switch	
reload	G	Halt and perform a cold	switch(config)# reload
		restart	
default	G	Restore to default	Switch(config)#default
admin username	G	Changes a login	switch(config)#admin username
[Username]		username.	xxxxxx
		(maximum 10 words)	
admin password	G	Specifies a password	switch(config)#admin password
[Password]		(maximum 10 words)	xxxxxx
show admin	Р	Show administrator	switch# show admin
		information	
dhcpserver enable	G	Enable DHCP Server	switch(config)#dhcpserver enable
dhcpserver lowip	G	Configure low IP	switch(config)#dhcpserver lowip
[Low IP]		address for IP pool	192.168.1.1
dhcpserver highip	G	Configure high IP	switch(config)#dhcpserver highip
[High IP]		address for IP pool	192.168.1.50
dhcpserver	G	Configure subnet mask	switch(config)#dhcpserver
subnetmask		for DHCP clients	subnetmask 255.255.255.0
[Subnet mask]			

dhcpserver gateway	G	Configure gateway for	switch(config)#dhcpserver
[Gateway]		DHCP clients	gateway 192.168.1.254
dhcpserver dnsip	G	Configure DNS IP for	switch(config)#dhcpserver dnsip
[DNS IP]		DHCP clients	192.168.1.1
dhcpserver leasetime	G	Configure lease time	switch(config)#dhcpserver
[Hours]		(in hour)	leasetime 1
dhcpserver ipbinding	I	Set static IP for DHCP	switch(config)#interface
[IP address]		clients by port	fastEthernet 2
			switch(config-if)# dhcpserver
			ipbinding 192.168.1.1
show dhcpserver	Р	Show configuration of	switch# show dhcpserver
configuration		DHCP server	configuration
show dhcpserver	Р	Show client entries of	switch#show dhcpserver clinets
clients		DHCP server	
show dhcpserver ip-	Р	Show IP-Binding	switch#show dhcpserver ip-
binding		information of DHCP	binding
		server	
no dhcpserver	G	Disable DHCP server	switch(config)#no dhcpserver
		function	
security enable	G	Enable IP security	switch(config)#security enable
		function	
security http	G	Enable IP security of	switch(config)#security http
		HTTP server	
security telnet	G	Enable IP security of	switch(config)#security telnet
		telnet server	
security ip	G	Set the IP security list	switch(config)#security ip 1
[Index(110)] [IP			192.168.1.55
Address]			

show security	Ρ	Show the information	switch#show security
		of IP security	
no security	G	Disable IP security	switch(config)#no security
		function	
no security http	G	Disable IP security of	switch(config)#no security http
		HTTP server	
no security telnet	G	Disable IP security of	switch(config)#no security telnet
		telnet server	
bsf rate	G	Configure Broadcast	switch(config)#bsf rate 1/2
		Storm Filter selection	
bsf flooded-unicast-	G	Enable Flooded	switch(config)#bsf flooded-
multicast		Unicast/Multicast	unicast-multicast
		Packets BSF	
bsf control	G	Enable Control	switch(config)#bsf control
		Packets BSF	
bsf ip-multicast	G	Enable IP Multicast	switch(config)#bsf ip-multicast
		Packets BSF	
bsf broadcast	G	Packets BSF	switch(config)#bsf broadcast
no bsf flooded-unicast-	G	Disable Flooded	switch(config)#no bsf flooded-
multicast		Unicast/Multicast	unicast-multicast
		Packets BSF	
no bsf control	G	Disable Control	switch(config)#no bsf control
		Packets BSF	
no bsf ip-multicast	G	Disable IP Multicast	switch(config)#no bsf ip-multicast
		Packets BSF	
no bsf broadcast	G	Disable Broadcast	switch(config)#no bsf broadcast
		Packets BSF	
jumbo-frame	G	Enable jumbo frame	switch(config)#jumbo-frame
no jumbo-frame	G	Disable jumbo frame	switch(config)#no jumbo-frame

show jumbo-frame	G	Show jumbo frame	switch# show jumbo-frame
		enable/disable	

Port Commands Set

Netstar Commands	Level	Description	Example
interface fastEthernet	G	Choose the port for	switch(config)#interface
[Portid]		modification.	fastEthernet 2
duplex	I	Use the duplex	switch(config)#interface
[full half]		configuration command	fastEthernet 2
		to specify the duplex	switch(config-if)#duplex full
		mode of operation for	
		Fast Ethernet.	
speed	I	Use the speed	switch(config)#interface
[10 100 1000 auto]		configuration command	fastEthernet 2
		to specify the speed	switch(config-if)#speed 100
		mode of operation for	
		Fast Ethernet, the	
		speed can't be set to	
		1000 if the port isn't a	
		giga port.	
flowcontrol	I	Use the flowcontrol	switch(config)#interface
[Enable Disable]		configuration command	fastEthernet 2
		on Ethernet ports to	switch(config-if)# flowcontrol
		control traffic rates	enable
		during congestion.	
no flowcontrol	I	Disable flow control of	switch(config-if)#no flowcontrol
		interface	
security enable	I	Enable security of	switch(config)#interface
		interface	fastEthernet 2
			switch(config-if)#security enable

no security	I	Disable security of	switch(config)#interface
		interface	fastEthernet 2
			switch(config-if)# no security
ratelimit in	I	Set interface input rate	switch(config)#interface
[Value]		limiting	fastEthernet 2
			switch(config-if)# ratelimit in 100
ratelimit out		Set interface output	switch(config)#interface
[Value]		rate limiting	fastEthernet 2
			switch(config-if)#ratelimit out 100
show ratelimit	I	Show interfaces rate	switch(config)#interface
		limiting	fastEthernet 2
			switch(config-if)#show ratelimit
state	I	Use the state interface	switch(config)#interface
[Enable Disable]		configuration command	fastEthernet 2
		to specify the state	switch(config-if)#state Disable
		mode of operation for	
		Ethernet ports. Use the	
		disable form of this	
		command to disable	
		the port.	
show interface	I	show interface	switch(config)#interface
configuration		configuration status	fastEthernet 2
			switch(config-if)#show interface
			configuration
show interface status	I	show interface actual	switch(config)#interface
		status	fastEthernet 2
			switch(config-if)#show interface
			status

show interface	I	show interface statistic	switch(config)#interface
accounting1		counter1	fastEthernet 2
			switch(config-if)#show interface
			accounting1
show interface	I	show interface statistic	switch(config)#interface
accounting2		counter2	fastEthernet 2
			switch(config-if)#show interface
			accounting2
no accounting	I	Clear interface	switch(config)#interface
		accounting information	fastEthernet 2
			switch(config-if)#no accounting
alias [name]	I	Configure alias name	switch(config)#interface
		of port	fastEthernet 2
			switch(config-if)#alias PORT002

Trunk Commands Set

Netstar Commands	Level	Description	Example
aggregator priority	G	Set port group system	switch(config)#aggregator priority
[1~65535]		priority	22
aggregator activityport	G	Set activity port	switch(config)#aggregator
[Group ID][Port			activityport 2 2
Numbers]			

aggregator group	G	Assign a trunk group	switch(config)#aggregator group
[GroupID] [Port-list]		with LACP active.	1 1-4 lacp workp 2
Іаср		[GroupID] :1~3	or
workp		[Port-list]:Member port	switch(config)#aggregator group
[Workport]		list, This parameter	2 1,4,3 lacp workp 3
		could be a port	
		range(ex.1-4) or a port	
		list separate by a	
		comma(ex.2, 3, 6)	
		[Workport]: The	
		amount of work ports,	
		this value could not be	
		less than zero or be	
		large than the amount	
		of member ports.	
aggregator group	G	Assign a static trunk	switch(config)#aggregator group
[GroupID] [Port-list]		group.	1 2-4 nolacp
nolacp		[GroupID] :1~3	or
		[Port-list]:Member port	switch(config)#aggreator group 1
		list, This parameter	3,1,2 nolacp
		could be a port	
		range(ex.1-4) or a port	
		list separate by a	
		comma(ex.2, 3, 6)	
show aggregator	Р	Show the information	switch#show aggregator 1
[Group-number]		of trunk group	

no aggregator lacp	G	Disable the LACP	switch(config)#no aggreator lacp
[GroupID]		function of trunk group	1
no aggregator group	G	Remove a trunk group	switch(config)# no aggreator
[GroupID]			group 2

VLAN Commands Set

Netstar Commands	Level	Description	Example
vlan database	Р	Enter VLAN configure	switch# vlan database
		mode	
vlanmode	V	To set switch VLAN	switch(vlan)#vlanmode portbase
[portbase 802.1q		mode.	or
gvrp]			switch(vlan)# vlanmode 802.1q
			or
			switch(vlan)# vlanmode gvrp
no vlan	V	Disable VLAN	Switch(vlan)# no vlan
Ported based VLAN	config	uration	
vlan port-based	V	Add new port based	switch(vlan)#vlan port-based
grpname		VALN	grpname test grpid 2 port 2-4
[Group Name]			
grpid			
[GroupID]			
port			
[PortNumbers]			
show vlan [GroupID]	V	Show VLAN	switch(vlan)# show vlan 23
or show vlan		information	
no vlan group	V	Delete port base group	switch(vlan)# no vlan group 2
[GroupID]		ID	

IEEE 802.1Q VLAN			
vlan 8021q name	V	Change the name of	switch(vlan)#vlan 8021q test vid
[GroupName]		VLAN group, if the	22
vid		group didn't exist, this	
[VID]		command can't be	
		applied.	
vlan 8021q port	V	Assign a access link	switch(vlan)#vlan 8021q port 3
[PortNumber]		for VLAN by port, if the	access-link untag 33
access-link untag		port belong to a trunk	
[UntaggedVID]		group, this command	
		can't be applied.	
vlan 8021q port	V	Assign a trunk link for	switch(vlan)#vlan 8021q port 3
[PortNumber]		VLAN by port. If the	trunk-link tag 2,3,6,99
trunk-link tag		port belongs to a trunk	or
[TaggedVID List]		group, this command	switch(vlan)# vlan 8021q port 3
		can't be applied.	trunk-link tag 3-20
vlan 8021q port	V	Assign a hybrid link for	switch(vlan)#vlan 8021q port 3
[PortNumber]		VLAN by port, if the	hybrid-link untag 4 tag 3,6,8
hybrid-link untag		port belong to a trunk	or
[UntaggedVID]		group, this command	switch(vlan)# vlan 8021q port 3
TaggedVID List]		can't be applied.	hybrid-link untag 5 tag 6-8
vlan 8021q trunk	V	Assign a access link	switch(vlan)#vlan 8021q trunk 3
[PortNumber]		for VLAN by trunk	access-link untag 33
access-link untag		group	
[UntaggedVID]	V	Assign a trunk link for	switch(vlap)#vlap 8021g trupk 3
[PortNumber]		VI AN by trunk aroun	trunk-link tag 2 3 6 90
trunk-link tag			ar and the second s
[TaggedVID List]			
			trunk-link tag 3-20

vlan 8021q trunk	V	Assign a hybrid link for	switch(vlan)#vlan 8021q trunk 3
[PortNumber] hybrid-link untag		VLAN by trunk group	hybrid-link untag 4 tag 3,6,8 or
[UntaggedVID] tag			switch(vlan)#vlan 8021q trunk 3
[TaggedVID List]			hybrid-link untag 5 tag 6-8
show vlan [GroupID] ^{or} show vlan	V	Show VLAN information	switch(vlan)# show vlan 23
no vlan group [GroupID]	V	Delete port base group ID	switch(vlan)# no vlan group 2

Spanning Tree Commands Set

Netstar Commands	Level	Description	Example
spanning-tree enable	G	Enable spanning tree	switch(config)#spanning-tree
			enable
spanning-tree priority	G	Configure spanning tree	switch(config)#spanning-tree
[0~61440]		priority parameter	priority 32768
spanning-tree max-age	G	Use the spanning-tree	switch(config)#spanning-tree
[seconds]		max-age global	max-age 15
		configuration command to	
		change the interval	
		between messages the	
		spanning tree receives	
		from the root switch. If a	
		switch does not receive a	
		bridge protocol data unit	
		(BPDU) message from the	
		root switch within this	
		interval, it recomputed the	
		Spanning Tree Protocol	
		(STP) topology.	

spanning-tree hello-	G	Use the spanning-tree	switch(config)# spanning-tree
time [seconds]		hello-time global	hello-time 3
		configuration command to	
		specify the interval	
		between hello bridge	
		protocol data units	
		(BPDUs).	
spanning-tree	G	Use the spanning-tree	switch(config)# spanning-tree
forward-time [seconds]		forward-time global	forward-time 20
		configuration command to	
		set the forwarding-time for	
		the specified spanning-	
		tree instances. The	
		forwarding time	
		determines how long each	
		of the listening and	
		learning states last before	
stp-path-cost		Use the spanning-tree cost	switch(config)# interface
[1~20000000]		interface configuration	fastEthernet 2
		command to set the path	switch(config-if)# stp-path-cost
		cost for Spanning Tree	20
		Protocol (STP)	
		calculations. In the event	
		of a loop, spanning tree	
		considers the path cost	
		when selecting	
		an interface to place into	
		the forwarding state.	

stp-path-priority	I	Use the spanning-tree	switch(config)#interface
[Port Priority]		port-priority interface	fastEthernet 2
		configuration command to	switch(config-if)# stp-path-
		configure a port priority	priority 127
		that is used when two	
		switches tie for position as	
		the root switch.	
stp-admin-p2p	I	Admin P2P of STP priority	switch(config)#interface
[Auto True False]		on this interface.	fastEthernet 2
			switch(config-if)#stp-admin-
			p2p Auto
stp-admin-edge	I	Admin Edge of STP	switch(config)#interface
[True False]		priority on this interface.	fastEthernet 2
			switch(config-if)#stp-admin-
			edge True
stp-admin-non-stp	I	Admin NonSTP of STP	switch(config)#interface
[True False]		priority on this interface.	fastEthernet 2
			switch(config-if)#stp-admin-
			non-stp False
show spanning-tree	Е	Display a summary of the	switch> show spanning-tree
		spanning-tree states.	
no spanning-tree	G	Disable spanning-tree.	switch(config)# no spanning-
			tree

QOS Commands Set

Netstar Commands	Level	Description	Example
qos priority-tos	G	Configure TOS Priority	switch(config)#qos priority-tos 9
[TosNum][Priority]			7
qos mode	G	Configure QOS mode	switch(config)# qos mode sp
[SP WRR WRR1 WRR2]			
qos 8021p-priority	G	Configure 8021p	switch(config)#qos 8021p-Priority
[Index][Lowest SecLow		Priority	1 lowest
SecHigh Highest]			
qos priority-portbased	I	Configure COS Priority	switch(config)#interface
[Priority]			fastEthernet 2
			switch(config-if)#qos priority- portbased 1

IGMP Commands Set

Netstar Commands	Level	Description	Example
igmp enable	G	Enable IGMP snooping	switch(config)#igmp enable
		function	
Igmp query auto	G	Set IGMP query to	switch(config)#igmp query auto
		auto mode	
Igmp query force	G	Set IGMP query to	switch(config)#igmp query force
		force mode	
igmp query-interval [1~250	G	Configure query	switch(config)# igmp query-
sec.]		interval	interval 10
igmp query-response-	G	Configure query	switch(config)# igmp query-
interval		response interval	response-interval 60
[1~250 tenths of a sec.]			
igmp last-query-count	G	Configure last member	switch(config)#igmp last-query-
[1~2]		query count	count 1

igmp last-query-	G	Configure last member	switch(config)#igmp last-query-
interval [1~250 tenths		query interval	interval 60
of a sec.]			
show igmp	Р	Show IGMP	switch#show igmp configuration
configuration		configuration	
show igmp table	Р	Show IGMP snooping	switch# show igmp multi
		table	
no igmp	G	Disable IGMP	switch(config)# no igmp
		snooping function	
no igmp-query	G	Disable IGMP query	switch# no igmp-query

Mac / Filter Table Commands Set

Netstar Commands	Level	Description	Example
mac-address-table	I	Configure MAC	switch(config)#interface
static hwaddr		address table of	fastEthernet 2
[HW-Addr][VID]		interface (static).	switch(config-if)#mac-address-
			table static hwaddr
			000012345678 1
mac-address-table	G	Configure MAC	switch(config)#mac-address-table
filter hwaddr		address table(filter)	filter hwaddr 000012348678 1
[HW-Addr][VID]			
show mac-address-	I	Show all MAC address	switch(config)#interface
table		table	fastEthernet 2
			switch(config-if)# show mac-
			address-table
show mac-address-	Р	Show static MAC	switch# show mac-address-table
table static		address table	static
show mac-address-	Р	Show filter MAC	switch#show mac-address-table
table filter		address table.	filter

no mac-address-table	I	Remove an entry of	switch(config)#interface
static hwaddr		MAC address table of	fastEthernet 2
[HW-Addr][VID]		interface (static)	switch(config-if)#no mac-address-
			table static hwaddr
			000012345678 1
no mac-address-table	G	Remove an entry of	switch(config)#no mac-address-
filter hwaddr		MAC address table	table filter hwaddr 000012348678
[HW-Addr][VID]		(filter)	1
no mac-address-table	G	Remove dynamic entry	switch(config)#no mac-address-
		of MAC address table	table
auto-age	G	Configure auto age	switch(config)#auto-age 150
[150 300 600]		time of MAC table	
no auto-age	G	Disable auto age time	switch(config)# no auto-age
		of MAC table	
show auto-age	Р	Display auto age time	switch# show auto-age
		of MAC table	
auto-flush	G	Enable auto flush MAC	switch(config)#auto-flush
		Table when link down	
no auto-flush	G	Disable auto flush	switch(config)#no auto-flush
		MAC Table when link	
		down	
show auto-flush	Р	Disable auto flush	switch# show auto-flush
		function of MAC table	
multicast-filtering	I	Configure multicast	switch(config)#interface
[IP-Addr][VID]		filtering entry of	fastEthernet 2
		interface	switch(config-if)#multicast-
			filtering 239.0.0.1 1

no multicast-filtering	I	Remove multicast	switch(config)#interface
[IP-Addr][VID]		filtering entry of	fastEthernet 2
		interface	switch(config-if)# no multicast-
			filtering 239.0.0.1 1
no multicast-filtering	G	Remove multicast	switch(config)#no multicast-
[IP-Addr][VID]		filtering entry	filtering 239.0.0.1 1
show multicast-	I	Show multicast filtering	switch#show multicast-filtering
filtering		table	

SNMP Commands Set

Netstar Commands	Level	Description	Example
snmp system-name	G	Set SNMP agent	switch(config)#snmp system-
[System Name]		system name	name I2switch
snmp system-location	G	Set SNMP agent	switch(config)#snmp system-
[System Location]		system location	location lab
snmp system-contact	G	Set SNMP agent	switch(config)#snmp system-
[System Contact]		system contact	contact where
snmp agent-mode	G	Select the agent mode	switch(config)#snmp agent-mode
[v1v2c v3 v1v2cv3]		of SNMP	v1v2cv3
snmp community-	G	Add SNMP community	switch(config)#snmp community-
strings [Community]		string.	strings public right rw
right			
[RO/RW]			
snmp-server host	G	Configure SNMP	switch(config)#snmp-server host
[IP address]		server host information	192.168.1.50 community public
community		and community string	trap-version v1
[Community-string]			(remove)
trap-version			Switch(config)# no snmp-server
[v1 v2c]			host 192.168.1.50

snmpv3 context-name	G	Configure the context	switch(config)#snmpv3 context-
[Context Name]		name	name Test
snmpv3 user	G	Configure the user	switch(config)#snmpv3 user
[User Name]		profile for SNMPV3	test01 group G1 password
group		agent. Privacy	AuthPW PrivPW
[Group Name]		password could be	
password		empty.	
[Authentication			
Password] [Privacy			
Password]			
snmpv3 access	G	Configure the access	switch(config)#snmpv3 access
context-name [Context		table of SNMPV3	context-name Test group G1
Name]		agent	security-level AuthPriv
group			match-rule Exact views V1 V1 V1
[Group Name]			
security-level			
[NoAuthNoPriv AuthNo			
Priv AuthPriv]			
match-rule			
[Exact Prifix]			
views			
[Read View Name]			
[Write View Name]			
[Notify View Name]			
snmpv3 mibview view	G	Configure the mibview	switch(config)#snmpv3 mibview
[View Name]		table of SNMPV3	view V1 type Excluded sub-oid
type		agent	1.3.6.1
[Excluded Included]			
sub-oid			
[OID]			

show snmp	Ρ	Show SNMP	switch# show snmp
		configuration	
no snmp community-	G	Remove the specified	switch(config)# no snmp
strings [Community]		community.	community-strings public
no snmp-server host	G	Remove the SNMP	switch(config)# no snmp-server
[Host-address]		server host.	host 192.168.1.50
no snmpv3 user	G	Remove specified user	switch(config)# no snmpv3 user
[User Name]		of SNMPv3 agent.	Test
no snmpv3 access	G	Remove specified	switch(config)# no snmpv3 access
context-name [Context		access table of	context-name Test group G1
Name]		SNMPv3 agent.	security-level AuthPr
group			iv match-rule Exact views V1 V1
[Group Name]			V1
security-level			
[NoAuthNoPriv AuthNo			
Priv AuthPriv]			
match-rule			
[Exact Prifix]			
views			
[Read View Name]			
[Write View Name]			
[Notify View Name]			
no snmpv3 mibview	G	Remove specified	switch(config)# no snmpv3
view		mibview table of	mibview view V1 type Excluded
[View Name]		SNMPV3 agent.	sub-oid 1.3.6.1
type			
[Excluded Included]			
sub-oid			
[OID]			

Port Mirroring Commands Set

Netstar Commands	Level	Description	Example
monitor destination	G	Set destination port	switch(config)#monitor
[Port ID]			destination 1
monitor source	G	Set source port	switch(config)#monitor source 2
[Port ID]			
monitor mode	G	Configure mode of	switch(config)#monitor mode rx
[RX TX Both Disabled]		monitor function	
show monitor	Р	Show port monitor information	switch# show monitor

802.1x Commands Set

Netstar Commands	Level	Description	Example
8021x enable	G	Use the 802.1x global	switch(config)#8021x enable
		configuration command	
		to enable 802.1x	
		protocols.	
8021x system	G	Use the 802.1x system	switch(config)#8021x system
radiousip [IP address]		radious IP global	radiousip 192.168.1.1
		configuration command	
		to change the radious	
		server IP.	
8021x system	G	Use the 802.1x system	switch(config)#8021x system
serverport [port ID]		server port global	serverport 1812
		configuration command	
		to change the radious	
		server port	

8021x system	G	Use the 802.1x system	switch(config)#8021x system
accountport [port ID]		account port global	accountport 1813
		configuration command	
		to change the	
		accounting port	
8021x system	G	Use the 802.1x system	switch(config)#8021x system
sharedkey [ID]		share key global	sharedkey 123456
		configuration command	
		to change the shared	
		key value.	
8021x system nasid	G	Use the 802.1x system	switch(config)#8021x system
[words]		nasid global	nasid test1
		configuration command	
		to change the NAS ID	
8021x misc quietperiod	G	Use the 802.1x misc	switch(config)#8021x misc
[sec.]		quiet period global	quietperiod 10
		configuration command	
		to specify the quiet	
		period value of the	
		switch.	
8021x misc txperiod	G	Use the 802.1x misc	switch(config)#8021x misc
[sec.]		TX period global	txperiod 5
		configuration command	
		to set the TX period.	
8021x misc	G	Use the 802.1x misc	switch(config)#8021x misc
supptimeout [sec.]		supp timeout global	supptimeout 20
		configuration command	
		to set the supplicant	
		timeout.	

8021x misc	G	Use the 802.1x misc	switch(config)#8021x misc
servertimeout [sec.]		server timeout global	servertimeout 20
		configuration command	
		to set the server	
		timeout.	
8021x misc	G	Use the 802.1x misc	switch(config)#8021x misc
maxrequest [number]		max request global	maxrequest 3
		configuration command	
		to set the MAX	
		requests.	
8021x misc	G	Use the 802.1x misc	switch(config)# 8021x misc
reauthperiod [sec.]		reauth period global	reauthperiod 3000
		configuration command	
		to set the reauth	
		period.	
8021x portstate	I	Use the 802.1x port	switch(config)#interface
[disable reject		state interface	fastethernet 2
accept authorize]		configuration command	switch(config-if)#8021x portstate
		to set the state of the	accept
		selected port.	
show 8021x	Е	Display a summary of	switch> show 8021x
		the 802.1x properties	
		and also the port sates.	
no 8021x	G	Disable 802.1x function	switch(config)# no 8021x

TFTP Commands Set

Netstar Commands	Level	Description	Example
backup	G	Save configuration to	switch(config)# backup
flash:backup_cfg		TFTP and need to	flash:backup_cfg
		specify the IP of TFTP	
		server and the file	
		name of image.	
restore	G	Get configuration from	switch(config)# restore
flash:restore_cfg		TFTP server and need	flash:restore_cfg
		to specify the IP of	
		TFTP server and the	
		file name of image.	
upgrade	G	Upgrade firmware by	switch(config)# upgrade
flash:upgrade_fw		TFTP and need to	flash:upgrade_fw
		specify the IP of TFTP	
		server and the file	
		name of image.	

SystemLog, SMTP and Event Commands Set

Netstar Commands	Level	Description	Example
systemlog ip	G	Set System log server	switch(config)#systemlog ip
[IP address]		IP address.	192.168.1.100
systemlog mode	G	Specified the log mode	switch(config)#systemlog mode
[client server both]			both
show systemlog	Е	Display system log.	Switch> show systemlog
show systemlog	Р	Show system log client	switch# show systemlog
		& server information	
no systemlog	G	Disable systemlog	switch(config)# no systemlog
		functon	
smtp enable	G	Enable SMTP function	switch(config)#smtp enable
smtp serverip	G	Configure SMTP	switch(config)#smtp serverip
[IP address]		server IP	192.168.1.5
smtp subject	G	Configure subject of	switch(config)#smtp subject test
[subject]		mail	
smtp sender	G	Configure sender of	switch(config)#smtp sender
[sender]		mail	tester
smtp authentication	G	Enable SMTP	switch(config)# smtp
		authentication	authentication
smtp account	G	Configure	switch(config)#smtp account
[account]		authentication account	User
smtp password	G	Configure	switch(config)#smtp password
[password]		authentication	
		password	
smtp rcptemail	G	Configure Rcpt e-mail	switch(config)#smtp rcptemail 1
[Index] [Email address]		Address	Alert@test.com
show smtp	Р	Show the information	switch# show smtp
		of SMTP	
no smtp	G	Disable SMTP function	switch(config)# no smtp

event device-cold-start	G	Set cold start event	switch(config)#event device-cold-
[Systemlog SMTP Both		type	start both
]			
event authentication-	G	Set Authentication	switch(config)# event
failure		failure event type	authentication-failure both
[Systemlog SMTP Both			
]			
event ring-topology-	G	Set X-ring topology	switch(config)#event ring-
change		changed event type	topology-change both
[Systemlog SMTP Both			
]			
event systemlog	I	Set port event for	switch(config)#interface
[Link-UP Link-		system log	fastethernet 2
Down Both]			switch(config-if)#event systemlog
			both
event smtp	I	Set port event for	switch(config)#interface
[Link-UP Link-		SMTP	fastethernet 2
Down Both]			switch(config-if)#event smtp both
show event	Р	Show event selection	switch# show event
no event device-cold-	G	Disable cold start event	switch(config)#no event device-
start		type	cold-start
no event	G	Disable Authentication	switch(config)# no event
authentication-failure		failure event type	authentication-failure
no event ring-	G	Disable super ring	switch(config)#no event ring-
topology-change		topology changed	topology-change
		event type	
no event systemlog	I	Disable port event for	switch(config)#interface
		system log	fastethernet 2
			switch(config-if)# no event
			systemlog

no event smpt	I	Disable port event for	switch(config)#interface
		SMTP	fastethernet 2
			switch(config-if)# no event smtp
show systemlog	Р	Show system log client	switch# show systemlog
		& server information	

SNTP Commands Set

Netstar Commands	Level	Description	Example
sntp enable	G	Enable SNTP function	switch(config)# sntp enable
sntp daylight	G	Enable daylight saving	switch(config)#sntp daylight
		time, if SNTP function	
		is inactive, this	
		command can't be	
		applied.	
sntp daylight-period	G	Set period of daylight	switch(config)#sntp daylight-
[Start time] [End time]		saving time, if SNTP	period 20060101-01:01
		function is inactive, this	20060202-01-01
		command can't be	
		applied.	
		Parameter format:	
		[yyyymmdd-hh:mm]	
sntp daylight-offset	G	Set offset of daylight	switch(config)#sntp daylight-
[Minute]		saving time, if SNTP	offset 3
		function is inactive, this	
		command can't be	
		applied.	

sntp ip [IP]	G	Set SNTP server IP, if	switch(config)#sntp ip 192.169.1.1
		SNTP function is	
		inactive, this command	
		can't be applied.	
sntp timezone	G	Set timezone index,	switch(config)#sntp timezone 22
[Timezone]		use "show sntp	
		timzezone" command	
		to get more information	
		of index number	
show sntp	Р	Show SNTP	switch# show sntp
		information	
show sntp timezone	Р	Show index number of	switch# show sntp timezone
		time zone list	
no sntp	G	Disable SNTP function	switch(config)# no sntp
no sntp daylight	G	Disable daylight saving	switch(config)#no sntp daylight
		time	

X-Ring Commands Set

Netstar Commands	Level	Description	Example
ring enable	G	Enable X-ring	switch(config)# ring enable
ring master	G	Enable ring master	switch(config)#ring master
ring ringport	G	Configure 1st/2nd Ring	switch(config)#ring ringport 7 8
[1st Ring Port] [2nd		Port	
Ring Port]			
ring couplering	G	Enable couple ring	switch(config)#ring couplering
ring couplering	G	Configure Coupling	switch(config)#ring couplering
couplingport		Port	couplingport 1
[Coupling Port]			
ring couplering	G	Configure Control Port	switch(config)#ring couplering
controlport			controlport 2
[Control Port]			
ring dualhoming	G	Enable dual homing	switch(config)#ring dualhoming
ring dualhoming	G	Configure Dual Homing	switch(config)#ring dualhoming
homingport		Port	homingport 3
[Dual Homing Port]			
show ring	Р	Show the information	switch# show ring
		of X-Ring	
no ring	G	Disable X-ring	switch(config)# no ring
no ring master	G	Disable ring master	switch(config)#no ring master
no ring couplering	G	Disable couple ring	switch(config)#no ring couplering
no ring dualhoming	G	Disable dual homing	switch(config)# no ring
			dualhoming

ring centralring	G	Enable and configure	switch(config)#ring centralring 1
[ring ID (1~4)] [1st Ring		central ring port	78
Port] [2nd Ring Port]			
no ring centralring	G	Disable central ring	switch(config)#no ring centralring
[ring ID (1~4)]			1

LLDP Command Set

Netstar Commands	Level	Description	Example
lldp enable	G	Enable LLDP function	switch(config)#IIdp enable
IIdp interval [TIME sec]	G	Configure LLDP	switch(config)#IIdp interval 10
		interval	
no lldp	G	Disable LLDP function	switch(config)# no IIdp
show lldp	Р	Show LLDP function	switch# show IIdp

Access Control List Command Set

Netstar Commands	Level	Description	Example
acl gid	G	Configure ACL group	switch(config)#acl gid 1
[Group ID]		id	
acl action	G	Configure ACL action	switch(config)#acl action permit
[Permit Deny]			
acl vid	G	Configure ACL VLAN	switch(config)#acl vid any
[Any VLAN ID]		ID	
acl pktype	G	Configure ACL packet	switch(config)#acl pktype ipv4
[IPv4 Non-IPv4]		type	
acl ethtype	G	Configure ACL ether	switch(config)#acl ethtype arp
[Any ARP IPX Type		type	
value]			
acl sip any	G	Any Src IP	switch(config)#acl sip any

acl sip ip	G	Specify Src IP and	switch(config)#acl sip ip
[IP address][Mask]		Mask	192.168.1.1 255.255.255.0
acl dip any	G	Any Des IP	switch(config)#acl dip any
acl dip ip	G	Specify Des IP and	switch(config)#acl dip ip
[IP address][Mask]		Mask	192.168.1.1 255.255.255.0
acl frg	G	Configure ACL IP	switch(config)#acl frg check
[Check Uncheck]		fragment	
acl I4 other	G	Configure ACL L4	switch(config)#acl I4 other any
[Any ICMP IGMP Proto		protocol other type	
col value]			
acl I4 tcp	G	Configure ACL L4	switch(config)#acl l4 tcp ftp
[Any FTP HTTP Port		protocol TCP	
Number]			
acl I4 udp	G	Configure ACL L4	switch(config)#acl I4 udp tftp
[Any TFTP Port		protocol UDP	
Number]			
acl add	G	Add new group	switch(config)#acl add
		structure	
acl show	G	Show content of	switch(config)#acl show
		current configured	
		ACL group.	
acl test	G	Debug command for	switch(config)#acl test 0
		ACL.	
no acl	G	Delete ACL group.	switch(config)#no acl 1
show acl	Р	Show ACL list.	switch# show acl

ComNet Customer Service

Customer Care is ComNet Technology's global service center, where our professional staff are ready to answer your questions at any time. Email address of ComNet Global Service Center: customercare@ComNet.net



World Headquarters

3 Corporate Drive Danbury, CT 06810 USA T 203 796-5300 F 203 796-5303 888 678-9427 Tech Support info@ComNet.net

ComNet Europe Ltd

8 Turnberry Park Road Gildersome, Morley Leeds, LS27 7LE, UK T +44 (0)113 307 6400 F +44 (0)113 253 7462 info-europe@ComNet.net

© 2010 Communication Networks, LLC. All rights reserved.

The COMNET logo is a registered trademark of Communication Networks Corporation. Additional Company and product names may be trademarks or registered trademarks of the individual companies and are respectfully acknowledged and do not imply endorsement.